

## AC Variable Speed Drives for Geared and Gearless Elevators

Part of the **OPTIDRIVE™** Family

## Quick Start-Up Instructions

	Page
Mechanical Installation	11
Electrical Installation	12
First Start-Up of Geared system without Encoder	24
First Start-Up of Geared system with Encoder	27
First Start-Up of Gearless (Permanent Magnet Motor)	31
Comfort Optimisation	36
Troubleshooting	53



For more Information

# 1. Contents

<b>1. Contents .....</b>	<b>2</b>
<b>2. About this Document .....</b>	<b>4</b>
2.1. Target Audience .....	4
2.2. Prerequisites .....	4
2.3. Terminology .....	4
2.4. Cyber Security .....	4
2.5. Warranty .....	4
<b>3. Safety First .....</b>	<b>5</b>
<b>4. Introduction .....</b>	<b>6</b>
4.1. General Information .....	6
4.2. Intended Application .....	7
4.2.1. Ambient temperature range: .....	7
4.2.2. Derating for Altitude: .....	7
<b>5. Product Familiarisation. ....</b>	<b>8</b>
5.1. Model Code Key .....	8
5.2. Product Layout .....	9
5.3. Encoder Module Layout .....	9
<b>6. Product Technical Information.....</b>	<b>10</b>
6.1. 200 – 240 Volt (+/-10%), 1 Phase Input (50-60Hz +/- 5%) .....	10
6.2. 200 – 240 Volt (+/-10%), 3 Phase Input (50-60Hz +/- 5%) .....	10
6.3. 380 – 480 Volt (+/-10%), 3 Phase Input (50-60Hz +/- 5%) .....	10
6.4. Voltage Trigger Levels .....	10
6.5. Rescue Operation .....	10
6.6. Energy Efficiency .....	10
<b>7. Mechanical Installation .....</b>	<b>11</b>
7.1. Preparing the drive for Mounting .....	11
7.2. Mounting Guidelines .....	11
7.3. Weights and Dimensions .....	11
<b>8. Electrical Installation .....</b>	<b>12</b>
8.1. Electrical Installation quick reference diagram .....	12
8.2. EMC Compliant Installation .....	13
8.2.1. Installation within the UK and European Union .....	13
8.2.2. Recommended Installation for EMC compliance .....	13
8.2.3. EMC bracket .....	13
8.3. Overall Wiring Diagram and default terminal functions .....	14
8.4. Encoder Wiring Connections .....	14
8.5. Cable Termination .....	15
8.6. Power Supply Connections .....	15
8.7. Motor Connections .....	15
8.8. Motor Contactors .....	15
8.9. Control Source Selection .....	16
8.10. Control Input Terminal Functions .....	16
8.10.1. Positive and Negative Logic .....	18
8.11. Control Output Terminal Functions .....	19
8.11.1. User Relays .....	19
8.11.2. Digital and Analogue Outputs .....	20
<b>9. Using the Keypad .....</b>	<b>21</b>
9.1. Keypad Layout and Function .....	21
9.2. Parameter Map .....	21
9.3. Changing Parameters .....	21
9.4. Resetting Parameters to Factory Default Settings .....	22
9.5. Resetting Parameters to OEM Default Settings .....	22
9.6. Showing Difference from defaults. ....	22
9.7. Drive Operating Displays .....	23
9.8. Elevator Specific Linear Units .....	23
<b>10. First Start-up of Geared (Induction) Motors without an Encoder.....</b>	<b>24</b>
10.1. Step 1- Wiring Connections .....	24
10.2. Step 2- Pre-Power Checks. ....	24
10.3. Step 3- Apply Power .....	25
10.4. Step 4- Motor nameplate data entry. ....	25

10.5.	Step 5- Motor Auto-tune .....	25
10.6.	Step 6 – Running the Elevator .....	26
<b>11.</b>	<b>First Start-up of Geared (Induction) Motors with an Encoder.....</b>	<b>27</b>
11.1.	Step 1- Wiring Connections.....	27
11.2.	Step 2- Pre-Power Checks .....	27
11.3.	Step 3- Apply Power.....	28
11.4.	Step 4- Motor nameplate data entry.....	28
11.5.	Step 5 - Encoder Setup .....	28
11.6.	Step 6- Motor Auto-tune. ....	29
	Step 7 – Running the Elevator .....	29
11.7.	29	
<b>12.</b>	<b>Start-up of Gearless (Permanent Magnet) Motor. ....</b>	<b>31</b>
12.1.	Step 1- Wiring Connections.....	31
12.2.	Step 2- Pre-Power Checks .....	31
12.3.	Step 3- Apply Power.....	31
12.4.	Step 4- Motor nameplate data entry.....	32
12.5.	Step 5- Encoder setup.....	32
12.6.	Step 6- Motor Auto-tune. ....	32
	Step 7 – Running the Elevator .....	33
12.7.	33	
<b>13.</b>	<b>Travel Curve Adjustment .....</b>	<b>34</b>
13.1.	Travel Curve Sequence.....	34
13.2.	Smooth Start Function .....	35
13.3.	Speed Loop Gains.....	35
<b>14.</b>	<b>Comfort Optimisation.....</b>	<b>36</b>
	Parameter Group 0 – Monitoring Parameters.....	40
<b>15.</b>	<b>40</b>	
<b>16.</b>	<b>Rescue Operation.....</b>	<b>46</b>
16.1.	UPS power supply connections.....	46
16.2.	Activating UPS Rescue mode .....	46
<b>17.</b>	<b>Serial communications .....</b>	<b>47</b>
17.1.	USB-C.....	47
17.2.	RS-485 communications.....	47
17.3.	PC Tool .....	47
<b>18.</b>	<b>Other Commonly Used Functions.....</b>	<b>48</b>
<b>19.</b>	<b>Safe Torque Off.....</b>	<b>49</b>
19.1.	Safe Torque Off.....	49
19.1.1.	Responsibilities.....	49
19.1.2.	What STO Provides.....	49
19.1.3.	What STO does not provide .....	49
19.1.4.	“STO” Operation.....	50
19.1.5.	“STO” Status and Monitoring .....	50
19.1.6.	“STO” Function response time .....	50
19.1.7.	“STO” Electrical Installation .....	51
19.1.8.	Recommended “STO” wiring.....	51
19.1.9.	External Power supply Specification. ....	51
19.1.10.	Safety Relay Specification. ....	51
19.1.11.	Enabling the “STO” Function .....	52
19.1.12.	Testing the “STO” Function .....	52
19.1.13.	“STO” Function Maintenance .....	52
<b>20.</b>	<b>Troubleshooting.....</b>	<b>53</b>
	Warning Messages .....	53
20.1.	53	
20.2.	Fault messages and Display messages .....	53
20.3.	Encoder Module Status LED's .....	57
<b>21.</b>	<b>Drive and Application Details.....</b>	<b>60</b>

## 2. About this Document

---

This document is intended as a Quick Start Up instruction manual and does not cover all features and functions of the product, the Elevator core reference manual is also available (Scan QR code on Front cover) which covers all features and functions in more detail.

### 2.1. Target Audience

The information detailed within this document is intended for those persons who will mechanically, and electrically install the drive, and those who will program the drive.

### 2.2. Prerequisites

The Installer and user must have Read and understood this manual and other applicable manuals in their entirety before proceeding.

### 2.3. Terminology

The word **Drive or Variable Frequency Drive** refers to this product, the **Optidrive Elevator Core**.

**IM** refers to Induction Motor.

**Geared** refers to Induction Motor.

**PM** refers to permanent magnet motor.

**Gearless** refers to permanent magnet motor.

### 2.4. Cyber Security

The overall system designer is responsible for ensuring that there is a maintained secure connection between the drive and any network that could be prone to a cyber-attack, furthermore the overall system designer is responsible for applying appropriate measures such as firewalls, data encryption etc..

Invertek Drives Ltd cannot be held responsible for any loss or damages regarding a Cyber Security breach.

### 2.5. Warranty

The manufacturer accepts no liability for any damage caused during or resulting from transport, receipt of delivery, installation or commissioning.

The manufacturer also accepts no liability for damage or consequences resulting from inappropriate, negligent or incorrect installation, incorrect adjustment of the operating parameters of the drive, incorrect matching of the drive to the motor, incorrect installation, unacceptable dust, moisture, corrosive substances, excessive vibration or ambient temperatures outside of the design specification.

The local distributor may offer different terms and conditions at their discretion, and in all cases concerning warranty, the local distributor should be contacted first.

This user guide is the "original instructions" document. All non-English versions are translations of the "original instructions".

The contents of this User Guide are believed to be correct at the time of printing. In the interest of a commitment to a policy of continuous improvement, the manufacturer reserves the right to change the specification of the product or its performance or the contents of the User Guide without notice.

### Copyright Invertek Drives Ltd © 2024

All rights reserved. No part of this User Guide may be reproduced or transmitted in any form or by any means, electrical or mechanical including photocopying, recording or by any information storage or retrieval system without permission in writing from the publisher.

### This User Manual is for use with version 1.0 Control Firmware and 1.03 Power Firmware

Invertek Drives Ltd adopts a policy of continuous improvement and whilst every effort has been made to provide accurate and up to date information, the information contained in this User Guide should be used for guidance purposes only and does not form the part of any contract.

### 3. Safety First

	<b>This manual is intended as a guide for proper installation. Invertek Drives Ltd cannot assume responsibility for the compliance or the non-compliance to any code, national, local or otherwise, for the proper installation of this drive or associated equipment. A hazard of personal injury and/or equipment damage exists if codes are ignored during installation.</b>	
	<b>This drive contains high voltage capacitors that take time to discharge after removal of the power supply. Before working on the drive, ensure isolation of all voltage sources, this includes Main AC supply, Battery supply, UPS supply. Wait ten (10) minutes for the capacitors to discharge to safe voltage levels. Failure to observe this precaution could result in severe bodily injury or loss of life.</b>	
	<b>Only qualified electrical personnel familiar with the construction and operation of this equipment and the hazards involved should install, adjust, operate, or service this equipment. Read and understand this manual and other applicable manuals in their entirety before proceeding. Failure to observe this precaution could result in severe bodily injury or loss of life.</b>	
	<b>Danger: Indicates a risk of electric shock, which, if not avoided, could result in damage to the equipment and possible injury or death.</b>	
		<b>Danger: Indicates a potentially hazardous situation other than electrical, which if not avoided, could result in damage to property.</b>

This variable speed drive product is intended for professional incorporation into complete equipment or systems as part of a fixed installation. If installed incorrectly it may present a safety hazard. The drive uses high voltages and currents, carries a high level of stored electrical energy, and is used to control mechanical plant that may cause injury. Close attention is required to system design and electrical installation to avoid hazards in either normal operation or in the event of equipment malfunction. Only qualified electricians are allowed to install and maintain this product.

System design, installation, commissioning and maintenance must be carried out only by personnel who have the necessary training and experience. They must carefully read this safety information and the instructions in this Guide and follow all information regarding transport, storage, installation and use of the drive, including the specified environmental limitations.

Do not perform any flash test or voltage withstand test on the drive. Any electrical measurements required should be carried out with the drive disconnected.

Electric shock hazard! Disconnect and ISOLATE the drive before attempting any work on it. High voltages are present at the terminals and within the drive for up to 10 minutes after disconnection of the electrical supply. Always ensure by using a suitable multimeter that no voltage is present on any drive power terminals prior to commencing any work.

Where supply to the drive is through a plug and socket connector, do not disconnect until 10 minutes have elapsed after turning off the supply.

Ensure correct earthing connections and cable selection as defined by local legislation or codes. The drive may have a leakage current of greater than 3.5mA; furthermore the earth cable must be sufficient to carry the maximum supply fault current which normally will be limited by the fuses or MCB. Suitably rated fuses or MCB should be fitted in the mains supply to the drive, according to any local legislation or codes.

Do not carry out any work on the drive control cables whilst power is applied to the drive or to the external control circuits.

The "Safe Torque Off" Function does not prevent high voltages from being present at the drive power terminals.

When installing the drive on any power supply where the phase-ground voltage may exceed the phase-phase voltage (typically IT supply networks or Marine vessels) it is essential that the internal EMC filter ground and surge protection varistor ground (where fitted) are disconnected. If in doubt, refer to your Sales Partner for further information.

Within the European Union, all machinery in which this product is used must comply with the Machinery Directive 2006/42/EC, Safety of Machinery. In particular, the machine manufacturer is responsible for ensuring that the electrical equipment complies with EN60204-1 and providing a disconnecting device which must be one of the following types:

- A switch-disconnector, utilization category AC-23B (EN 60947-3).
- A circuit breaker suitable for isolation in accordance with EN 60947-2.
- A disconnector with an integrated auxiliary contact that ensures under all circumstances the switching devices break the load circuit prior to opening of the main contacts of the disconnector (EN 60947-3).

For installation in other regions, conformance with local electrical regulations and codes of practice must be adhered to.

The level of integrity offered by the drive control input functions – for example stop/start, forward/reverse and maximum speed, is not sufficient for use in safety-critical applications without independent channels of protection. All applications where malfunction could cause injury or loss of life must be subject to a risk assessment and further protection provided where needed.

The driven motor can start at power up if the enable/run input signals are present.

The STOP function does not remove potentially lethal high voltages. ISOLATE the drive and wait 10 minutes before starting any work on it.

Never carry out any work on the Drive, Motor or Motor cable whilst the input power is still applied.

The drive can be programmed to operate the driven motor at speeds above or below the speed achieved when connecting the motor directly to the mains supply. Obtain confirmation from the manufacturers of the motor and the driven machine about suitability for operation over the intended speed range prior to machine start up.

Do not activate the automatic fault reset function on any systems whereby this may cause a potentially dangerous situation.

The drive must be installed in a pollution degree 2 environment, mounted in a cabinet with IP54 or better.

The drive is intended for indoor use only.

When mounting the drive, ensure that sufficient cooling is provided.

Do not carry out drilling operations with the drive in place, dust and swarf from drilling may lead to damage.

The entry of conductive or flammable foreign bodies should be prevented. Flammable material should not be placed close to the drive.

Relative humidity must be less than 95% (non-condensing).

Ensure that the supply voltage, frequency and no. of phases (1 or 3 phase) correspond to the rating of the drive as delivered.

Never connect the mains power supply to the Output terminals U, V, W.

Do not install any type of automatic switchgear between the drive and the motor which can switch state whilst the drive is running.

Wherever control cabling is close to power cabling, maintain a minimum separation of 100 mm and arrange crossings at 90 degrees. Ensure that all terminals are tightened to the appropriate torque setting.

Do not attempt to carry out any repair of the drive. In the case of suspected fault or malfunction, contact your local Invertek Drives Sales Partner for further assistance.

Do not operate the drive with any of the enclosure covers removed.

## 4. Introduction

### 4.1. General Information

It is the responsibility of the installer to ensure that the equipment or system into which the product is incorporated complies with all relevant legislation and codes of practice which apply in the country of use.

#### CE Marking

All Invertek Drives products intended for use within the European Union carry the CE mark to indicate compliance with European Directives (EMC Directive, Low Voltage Directive and Machinery Directive). A declaration of conformity is available from the website, [www.invertekdrives.com](http://www.invertekdrives.com). For compliance with the European EMC Directive, the necessary guidance is provided within this document and it is the responsibility of the installer to ensure this guidance is followed to ensure compliance.

#### UKCA Marking

All Invertek Drives products intended for use within the United Kingdom carry the UKCA mark to indicate compliance with Following UK regulations: Electromagnetic Compatibility Regulations, Supply of Machinery (Safety) Regulations, Electrical Equipment (Safety) Regulations. A declaration of conformity is available from the website, [www.invertekdrives.com](http://www.invertekdrives.com). For compliance with the relevant sections of the above regulations, the necessary guidance is provided within this document and it is the responsibility of the installer to ensure this guidance is followed to ensure compliance.

#### UL Conformity

A list of currently listed products is available from the UL website, [www.ul.com](http://www.ul.com). For compliance with UL requirements, the necessary guidance is provided within this document and it is the responsibility of the installer to ensure this guidance is followed to ensure compliance.

#### Safe Torque OFF (“STO”) Function

The drive incorporates a hardware STO (Safe Torque Off) Function, designed in accordance with the standards listed below.

Standard	Classification	Independent Approval
EN 61800-5-2:2017	SIL3	*TUV
EN ISO 13849-1:2015	PL “e”	
EN 61508 (Part 1 to 7):2010	SIL3	
EN60204-1:2006 + A1:2009 + AC: 2010	Uncontrolled Stop “Category 0”	
EN 62061:2021	SIL3	

\*NOTE TUV Approval of the “STO” function is relevant for drives which have a TUV logo applied on the drive rating label. The STO input must not be used for any safety related function if the drive unit does not carry the TUV logo on the rating label.

#### Unintended Car Movement

Brake Contact Monitoring (Unintended Car Movement) EN 81-20:2014+A3 (certification by Lift Institute)

#### Contactless Operation

The drive can be used without a Motor contactor using the Safe Torque Off inputs according to parts of EN 81-20:2014 and EN 81-50:2014 (certification by Lift Institute)

## 4.2. Intended Application

The elevator Core drive is intended to control the motor of Counterweighted Traction passenger Elevators, and not intended for hydraulic Elevators.

The elevator Core drive can control Induction or permanent magnet IPM (Internal Permanent Magnet) or SPM (Surface Mounted Permanent Magnet) motor types.

It is the responsibility of the installer to ensure that the equipment or system into which the product is incorporated complies with all relevant legislation and codes of practice which apply in the country of use.

### 4.2.1. Ambient temperature range:

Operational	: -20 ... 50°C
Storage and Transportation	: -40 °C ... 60 °C
Max altitude for rated operation	: 1000m
Relative Humidity	: < 95% (non-condensing)

Note : Drive must be Frost and moisture free at all times  
Installation above 2000m is not UL approved

### 4.2.2. Derating for Altitude:


Derating of the drive maximum continuous output current capacity is required when Operating at Altitudes more than 1000m/ 3281 ft

The following derating factors should be applied when operating drives outside of these conditions


Maximum Altitude Without Derating	Derate by	Maximum Permissible (UL Approved)	Maximum Permissible (Non-UL Approved)
1000m / 3281ft	1% per 100m / 328 ft	2000m / 6562 ft	4000m / 13123 ft

## 5. Product Familiarisation.

### 5.1. Model Code Key




## 5.2. Product Layout



1	Power Supply Input Terminals
2	USB-C Port -Used to light up the drive display and allow drive programming and parameter viewing using a device with USB-C output
3	Optional Universal Encoder Module for closed loop operation
4	Motor Connection Terminals
5	RJ45 Port for Modbus RTU / CAN open / PC interface (NOT FOR ETHERNET!)
6	Digital Inputs/Outputs
7	Safe Torque-Off Inputs
8	Drive Serial Number and Rating
9	Digital, Analogue Inputs/Outputs
10	Motor Brake Control Output
11	Motor Contactor Control Output (Default Function)
12	Trip reset Button (In addition to terminal & network reset)
13	Input EMC Filter and Varistor Circuit to earth Disconnect
14	DC Link EMC Filter Circuit to earth Disconnect
15	Brake Resistor Connection Terminals (Only Connect brake resistor between +DC and BR)
16	Encoder Status LED's
17	QR Code for on-line support documentation

## 5.3. Encoder Module Layout

- Red = Power on
- Off = No power
- Off = Module Inactive
- Green = Healthy
- Green Flashing = Error



## 6. Product Technical Information

### 6.1. 200 – 240 Volt (+/-10%), 1 Phase Input (50-60Hz +/- 5%)

Model Code	Power Rating		Frame Size	Input Current A	Fuse or MCB (Type B)		Maximum Cable Size		Rated Output Current A	Overload	Recommended Brake Resistance Ω (Minimum)	*Resistor power rating (W)
	kW	HP			Non UL	UL	mm	AWG/kcmil				
ODL-3-220105-142SB_	2.2	3	2	22	25	25	6	10	10.5	150% 60 sec's / 200% 2 sec's	35	1000

### 6.2. 200 – 240 Volt (+/-10%), 3 Phase Input (50-60Hz +/- 5%)

Model Code	Power Rating		Frame Size	Input Current A	Fuse or MCB (Type B)		Maximum Cable Size		Rated Output Current A	Overload	Recommended Brake Resistance Ω (Minimum)	*Resistor power rating (W)
	kW	HP			Non UL	UL	mm	AWG/kcmil				
ODL-3-220180-342SB_	4	5	2	22	25	30	6	10	18	150% 60 sec's / 200% 2 sec's	20	1000
ODL-3-220240-342SB_	5.5	7.5	2	27	32	35	6	10	24		20	1500
ODL-3-320300-342SB_	7.5	10.0	3	34	40	40	16	6	30.0		20	2000

### 6.3. 380 – 480 Volt (+/-10%), 3 Phase Input (50-60Hz +/- 5%)

Model Code	Power Rating		Frame Size	Input Current A	Fuse or MCB (Type B)		Maximum Cable Size		Rated Output Current A	Overload	Recommended Brake Resistance Ω (Minimum)	*Resistor power rating (W)
	kW	HP			Non UL	UL	mm	AWG/kcmil				
ODL-3-240095-342SB_	4	5	2	14	16	20	6	10	9.5	150% 60 sec's / 200% 2 sec's	100	1000
ODL-3-240140-342SB_	5.5	7.5	2	21	32	30	6	10	14		75	1500
ODL-3-340180-342SB_	7.5	10	3	24	32	35	16	6	18		50	2000
ODL-3-340240-342SB_	11	15	3	30	40	40	16	6	24		40	3000
ODL-3-340300-342SB_	15	20	3	38	50	60	16	6	30.0		50	4000

### 6.4. Voltage Trigger Levels

	200-240V Rated Drive	380-480V Rated Drive
Braking Resistor Turn-On Voltage	390Vdc	780Vdc
Overvoltage	418Vdc	835Vdc
Undervoltage	160Vdc	320Vdc

### 6.5. Rescue Operation

Rescue Power Supply type	Required Connections	Nominal Rating	Minimum Voltage	Maximum Voltage	Current Requirements
UPS Power Supply	UPS must be connected to terminals L1 and L2	230VAC 1Ph	160VAC (226Vdc)	280VAC	Motor Rated current (P4-03) and considering overload, typically no greater than 200%
Battery Power Supply	High Power connections to terminals +DC and -DC		32Vdc (<24Vdc will result in an undervoltage trip)	200-240V drives = 340Vdc 380-480V drives = 680Vdc	
	Control +24V connection to terminals 0V and +24V	24V	20V	26V	2.2A (60W)

#### Notes

- Ratings shown above apply to 50°C ambient temperature and a maximum of 10kHz switching frequency.
- For UL compliant installation, use Copper wire with a minimum insulation temperature rating of 70°C, and UL Class CC or Class J Fuses
- For Non-UL/ IEC installation use gG fuses
- To meet UL regulations, UL approved ring crimp terminals should be used for all ground wiring connections
- Input currents assuming a minimum of 1% supply impedance for single phase input drives, the input current can be reduced by increasing the supply impedance by installing input chokes.
- Input currents can vary from those shown depending on supply voltage and supply impedance.
- All 3 phase input drives have phase imbalance monitoring. A phase imbalance of > 3% will result in the drive tripping. For input supplies which have supply imbalance greater than 3% (typically the Indian sub- continent & parts of Asia Pacific including China) Inverterk Drives recommends the installation of input line reactors.

\*The Resistor power rating shown are guideline only, the values should be calculated based on the individual application, considering the braking power and duty cycle of the elevator.

### 6.6. Energy Efficiency

Typical drive heat losses are 3% of operating load conditions.

For more detailed information please visit [www.inverterkdrives.com/ecodesign](http://www.inverterkdrives.com/ecodesign) to learn more about the Ecodesign Directive and for specific product efficiency classification and part load loss data in accordance with IEC 61800-9-2:2017

## 7. Mechanical Installation


### 7.1. Preparing the drive for Mounting

Carefully remove the drive from its carton, check for damage etc.. Notify the shipper immediately if any exist.

### 7.2. Mounting Guidelines

- The drive should be mounted prior to any wires being connected to the drive.
- For ease of installation the drive packaging carton has a mounting template to follow, ensuring dust from drilling does not enter the drive.
- Installation should be in a suitable enclosure, according to EN60529 or other relevant local codes or standards.
- Enclosures should be made from a thermally conductive material.
- Where vented enclosures are used, there should be venting above the drive and below the drive to ensure good air circulation, Air should be drawn in below the drive and expelled above the drive.
- In any environments where the conditions require it, the enclosure must be designed to protect the drive against ingress of airborne dust, corrosive gases or liquids, conductive contaminants (such as condensation, carbon dust, and metallic particles) and sprays or splashing water from all directions.
- High moisture, salt or chemical content environments should use a suitably sealed (non-vented) enclosure.
- The drive should be mounted in a vertical position only, on a flat, flame resistant, vibration free mounting using the integral mounting holes.
- The drive must be installed in a pollution degree 1 or 2 environment only.
- Do not mount flammable material close to the drive.
- For drives mounted in non-ventilated metallic enclosures ensure that the minimum clearances below are met.
- Ensure that the ambient temperature where the drive will be installed does not exceed 50°C or below -20°C
- Ensure that the height above sea level where the drive will be installed does not exceed 1000m, if it does then refer to section 4.2.2
- Provide suitable clean, moisture and contaminant free cooling air sufficient to fulfil the cooling requirements of the drive.

#### Using the DIN Rail mount on Frame Size 2




Patent pending GB 2625869.

#### Using the Mounting Points

Mounting Bolts		
Frame Size	Metric	UNF
2	M5	#10
3	M5	#10



#### Clearances around the drive




Drive Size	X		Y	
	mm	in	mm	in
2	75	2.95	50	1.97
3	100	3.94	50	1.97

### 7.3. Weights and Dimensions

Note: Dimensions Include Encoder module but not Cable support brackets

Drive Size	H		W		D		Weight	
	mm	in	mm	in	mm	in	Kg	lb
2	220	8.66	110	4.33	184	7.24	1.8	4.0
3	264	10.39	131	5.16	207	8.15	3.5	7.7



#### Installing the Encoder Module



## 8. Electrical Installation

### 8.1. Electrical Installation quick reference diagram

The diagram illustrates the electrical installation for an Invertertek drive. It shows the power supply path starting from the grid, passing through an Isolator, Fuses / Circuit breaker, Line Reactor Option, RFI Filter Option, and Output Filter Option, finally reaching the drive and the motor. Control connections are shown on the left: a smartphone connected via USB-USB-C Isolated cable, a laptop connected via Modbus to USB Isolated cable, CANopen, and Modbus RTU.

- Check Supply Voltage does not exceed drive Voltage rating as shown on rating label.
- Check the number of supply phases is compatible with the drive as shown on rating label.
- If the power supply has a low supply impedance /high short circuit current a Line reactor/Isolation transformer maybe required.
- For generator Bourne power supplies please contact your Invertek sales partner for further guidance.

• Ensure there is at least 30 seconds between each power-on.

- Install suitably rated fuses/Circuit breakers
- If an earth leakage detection device is used (e.g.ELCB/RCD), a type B trip characteristic which is suitable for protecting equipment with a DC component should be used, 1 device for multiple drives should be avoided.

Install Line reactor as close to the drive as possible and under the following conditions:

- If phase-phase imbalance is >3% (3Ø drives).
- To reduce Inrush current.
- If power supply has a low supply impedance/high short circuit current.
- If power supply is prone to dips or brown-outs.
- If power supply is via a bus-bar and sliding contacts system.
- Reduction in mains Harmonic emission.

- Install External EMC filter if the motor cable length exceeds the Electromagnetic interference reduction capability of the internal filter
- Do Not Use EMC filters on IT (Ungrounded) or a corner grounded TN power supply systems.

Functionality of control terminals is pre-configured according to parameter P1-02, default functionality is shown below :

DI1	DI2	DI3	DI4	DI5	DI6	DI7	DI8
Open Disabled/ Close Forward	Open Disabled/ Close Reverse	Open Disabled/ Levelling Speed (P8-05)	Open Disabled/ High Speed (P8-06)	Open Disabled/ High Speed 5 (P8-12)	Open Disabled/ Inspection Speed (P8-08)	Fault Reset	Rescue Mode Enable

The drive will only start if all the below conditions are met:

- Safe Torque off inputs are enabled.

The Safety Chain diagram shows two normally closed switches connected to Drive Inhibit terminals ST01 and ST02, and a 24V supply.

- A direction Command (DI1 or DI2) has been given.
- At least 1 speed has been selected.

Note : If more than 1 speed selection input is high the highest speed will be used.

Install Output Choke under the following conditions:

- If cable between the drive and motor exceeds 100m (screened cable), or 150m (un-screened cable).
- If motor is not “inverter rated”.


Encoder Wiring:  
The encoder cable should be screened, ideally with each signal pair individually screened. The screen should be connected to the 0V of the encoder module, or shield/screen connection.

## 8.2. EMC Compliant Installation

### 8.2.1. Installation within the UK and European Union

All equipment installed within the UK or European Union must comply with the applicable UK or European EMC Directive. The installer must be familiar with the Directive and appropriate good EMC practice. Invertek Drives' products may be considered as a Basic Drive Module or Complete Drive Module according to the EMC standard definition dependent on the drive type. The BDM or CDM may then be incorporated into a Power Drive System. It is the sole responsibility of the installer to ensure that the complete PDS is compliant with the Directive.


The diagram below provides general guidance to ensure compliance can be achieved.



### 8.3. Overall Wiring Diagram and default terminal functions



Before making any wiring connections ensure that all voltage/power sources are isolated.



### 8.4. Encoder Wiring Connections


Encoder Type	24V	0V	5V	A+/Sin+	A-/Sin-	B+/Cos+	B-/Cos-	C+ CLOCK	C- /CLOCK	D+ DATA	D- /DATA	Shield
Incremental TTL Differential		0V	5V	A+	A-	B+	B-					Cable Shield
Incremental HTL Differential	24V	0V		A+	A-	B+	B-					
Incremental TTL		0V	5V	A	Connect to 0V	B	Connect to 0V					
Incremental HTL	24V	0V		A	Connect to 0V	B	Connect to 0V					
SinCos (ERN 1387)		0V	5V	A+	A-	B+	B-	C+	C-	D+	D-	
Endat with Incremental Signals		0V	5V	A+	A-	B+	B-	CLOCK	/CLOCK	DATA	/DATA	
Endat without Incremental Signals		0V	5V					CLOCK	/CLOCK	DATA	/DATA	

## 8.5. Cable Termination

The terminals are designed to accept the following termination methods (Bare conductor or Ferrule)




## 8.6. Power Supply Connections



- It is recommended that the power cabling should be 4-core PVC-insulated screened cable and laid in accordance with local industrial regulations and codes of practice.
- The cables should be dimensioned according to any local codes or regulations. Guideline dimensions are given in section 6 Product Technical Information.
- Suitable fuses to provide wiring protection of the input power cable should be installed in the incoming supply line, recommended ratings are given in section 6 Product Technical Information.. The fuses must comply with any local codes or regulations in place. In general, type gG (IEC 60269) or UL type T fuses are suitable; however, in some cases type aR fuses may be required. The operating time of the fuses must be below 0.5 seconds.

- A fixed installation is required according to IEC61800-5-1 with a suitable disconnecting device installed between the drive and the AC Power Source. The disconnecting device must conform to the local safety code / regulations (e.g. within Europe, EN60204-1, Safety of machinery).
- Where allowed by local regulations, suitably dimensioned type B MCB circuit breakers of equivalent rating may be utilised in place of fuses, providing that the clearing capacity is sufficient for the installation.
- The maximum permissible short circuit current at the drive Power terminals as defined in IEC60439-1 is 100kA.
- When the power supply is removed from the drive, a minimum of 30 seconds should be allowed before re-applying the power. A minimum of 5 minutes should be allowed before removing the terminal covers or connection.
- An optional Input Choke/Line reactor is recommended to be installed in the supply line for drives where any of the following conditions occur:-
  - The incoming supply impedance is low or the fault level / short circuit current is high
  - The supply is prone to dips or brown outs
  - An imbalance exists on the supply (3 phase drives)
  - The power supply to the drive is via a busbar and brush gear system.
- In all other installations, an input choke is recommended to ensure protection of the drive against power supply faults

## 8.7. Motor Connections



- There are sometimes multiple connections within the motor terminal box, in general: Star and Delta. It is essential to ensure that the motor is connected in accordance with the voltage at which it will be operated.
- Maximum Motor cable length for shielded type cables is 100mtrs/330ft (150mtrs/495ft for un-shielded cables).
  - Note that the maximum motor cable length stated is the maximum permissible cable length for the drive hardware and does not take into consideration EMC compliance.
  - The motor earth must be connected to one of the drive earth terminals.
  - The cable screen should be terminated at the motor end using an EMC type gland allowing connection to the motor body through the largest possible surface area.
- The PWM output switching from any inverter when used with a long motor cable length can cause an increase in the voltage at the motor terminals, depending on the motor cable length and inductance. The rise time and peak voltage can affect the service life of the motor. Invertek Drives recommend using an output choke for motor cable lengths of 50m or more to ensure good motor service life.
- The motor must be connected to the drive U, V, and W terminals using a suitable 3 or 4 core cable. Where a 3 core cable is utilised, with the shield operating as an earth conductor, the shield must have a cross sectional area at least equal to the phase conductors when they are made from the same material. Where a 4 core cable is utilised, the earth conductor must be of at least equal cross sectional area and manufactured from the same material as the phase conductors.
- For compliance with the European EMC directive, a suitable screened (shielded) cable should be used. Braided or twisted type screened cable where the screen covers at least 85% of the cable surface area, designed with low impedance to HF signals are recommended as a minimum. Installation within a suitable steel or copper tube is generally also acceptable.
- Where drives are mounted in a steel control panel enclosure, the cable screen should be terminated directly to the control panel using a suitable EMC clamp or gland, as close to the drive as possible and as illustrated in section 8.2 alternatively the optional EMC cable bracket should be used as per shown in section 8.2.

## 8.8. Motor Contactors

Do not install any type of automatic switchgear between the drive and the motor which will change state whilst the drive is running, failure to do so will likely result in damage to the contactors as well as nuisance drive errors.

The drive STO SIL3 Inputs can be used to replace the motor contactors according to parts of EN 81-20:2014 and EN 81-50:2014.

### 8.9. Control Source Selection

From default the drive is set to operate from the control terminals (Discrete Inputs), control from a different method (Modbus rtu/CANopen) can be achieved by changing the Primary Command Source in parameter P1-01.

P1-01	Primary Command Source	
Setting	Start, direction and Speed reference source	
<b>TER</b> (Default)	The drive responds directly to control signals applied to the drive control terminals. Terminal designations assigned with parameter P1-02.	
<b>rtu</b>	The drive responds to Modbus RTU commands sent to the RJ45 port on the drive.	
<b>CAN</b>	The drive responds to CAN bus commands sent to the RJ45 port on the drive.	
<p><b>* Note :</b> The drive will not start unless safe Torque inputs STO1 and STO2 are closed.</p>		

### 8.10. Control Input Terminal Functions

The status of the control terminals can be monitored using parameter P0-01 and P0-02.

<b>P0-01 Display value</b>	0	0	0	0	0
<b>Function</b>	Digital Input 1 status	Digital Input 2 status	Digital Input 3 status	Digital Input 4 status	Digital Input 5 status
<b>P0-02 Display value</b>	0	0	0	0	0
<b>Function</b>	Digital Input 6 status	Digital Input 7 status	Digital Input 8 status	Daux 1 Input Status	Daux 2 Input Status

Use the Macro tables below to select an appropriate value of P1-02 to match the elevator controller output signals.

E.g. if P1-02 = 1 then high speed is selected when terminal DI4 is on and P0-01 will show 00010

P1-02 Value ↓	Drive Control Input Terminals								Speed Source
	DI1	DI2	DI3	DI4	DI5	DI6	DI7	DI8	
0	User Configurable using group 12.								
*1 (Default)	*Open Disabled/ Close Forward	*Open Disabled/ Close Reverse	*Open Disabled/ Levelling Speed (P8-05)	*Open Disabled/ High Speed(P8-06)	*Open Disabled/ High Speed 5/Relevelling Speed (P8-12)	*Open Disabled/ Inspection Speed (P8-08)	Fault Reset	Rescue Mode Enable	If more than 1 speed selection input is high the highest speed will be used.
*2	*Open Disabled/ Close Forward	*Open Disabled/ Close Reverse	*Open Disabled/ Levelling Speed (P8-05)	*Open Disabled/ High Speed(P8-06)	Ok when closed / E-Trip when open or thermistor trip if thermistor function selected in P1-09 Analog Input 2 (DI5) Format or motor contactor feedback trip if P3-02 is set to 1 (Enabled)	*Open Disabled/ Inspection Speed (P8-08)	Fault Reset	Rescue Mode Enable	

\*For settings 1 and 2 above, the drive will only start if all the below conditions are met:

- Safe Torque off inputs are enabled.
- A direction Command (DI1 or DI2) has been given.
- At least 1 speed has been selected.

Note : If more than 1 speed selection input is high the highest speed will be used.

P1-02 Value ↓	Drive Control Input Terminals								Speed Source
	DI1	DI2	DI3	DI4	DI5	DI6	DI7	DI8	
3	Open Disabled/ Close Forward	Open Disabled/ Close Reverse	1	0	0	Ok when closed / E-Trip when open or motor contactor feedback trip if P3-02 is set to 1 (Enabled)	Fault Reset	Rescue Mode Enable	P8-06 (High Speed)
			0 or 1	0	1				P8-07 (Intermediate Speed)
			0 or 1	1	0 or 1				P8-08 (Inspection Speed)
			0	0	0				P8-05 (Levelling Speed)
4	Open Disabled/ Close Forward	Open Disabled/ Close Reverse	1	0	Ok when closed / E-Trip when open or thermistor trip if thermistor function selected in P1-09 Analog Input 2 (DI5) Format or motor contactor feedback trip if P3-02 is set to 1 (Enabled)	0	Fault Reset	Rescue Mode Enable	P8-06 (High Speed)
			0 or 1	0		1			P8-07 (Intermediate Speed)
			0 or 1	1		0 or 1			P8-08 (Inspection Speed)
			0	0		0			P8-05 (Levelling Speed)
5	Open Disabled/ Close Forward	Open Disabled/ Close Reverse	0	0	0	Ok when closed / E-Trip when open or motor contactor feedback trip if P3-02 is set to 1 (Enabled)	Fault Reset	Rescue Mode Enable	P8-05 (Levelling Speed)
			1	0	0				P8-06 (High Speed)
			0	1	0				P8-07 (Intermediate Speed)
			1	1	0				P8-08 (Inspection Speed)
			0	0	1				P8-09 (Speed 2)
			1	0	1				P8-10 (Speed 3)
			0	1	1				P8-11 (Speed 4)
			1	1	1				P8-12 (Speed 5)
6	Open Disabled/ Close Forward	Open Disabled/ Close Reverse	Off	Speed Reference from Analogue input	Ok when closed / E-Trip when open or thermistor trip if thermistor function selected in P1-09	Ok when closed / E-Trip when open or motor contactor feedback trip if P3-02 is set to 1 (Enabled)	Fault Reset	Rescue Mode Enable	Analogue input Ref level
*7	*Open Disabled/ Close Forward	*Open Disabled/ Close Reverse	*Open Disabled/ Levelling Speed (P8-05)	Torque Sensor Input	*Open Disabled/ High Speed (P8-06)	*Open Disabled/ Inspection Speed (P8-08)	Fault Reset	Rescue Mode Enable	If more than 1 speed selection input is high the highest speed will be used.

\*For setting 7 above, the drive will only start if all the below conditions are met:

- Safe Torque off inputs are enabled.
- A direction command (DI1 or DI2) has been given.
- At least 1 speed has been selected.

P1-02 Value ↓	Drive Control Input Terminals								Speed Source
	DI1	DI2	DI3	DI4	DI5	DI6	DI7	DI8	
8	Open Disabled/ Close Forward	Open Disabled/ Close Reverse	0	0	Brake Release Monitor Input 1	Brake Release Monitor Input 2	Fault Reset	Rescue Mode Enable	P8-05 (Levelling Speed)
			1	0					P8-06 (High Speed)
			0	1	(Only Active if P5-04 Brake Release Monitoring Enable is set to a value of 2)	(Only Active if P5-04 Brake Release Monitoring Enable is set to a value of 2)			
			1	1	P8-08 (Inspection Speed)				
*9	Forward Direction Select	Reverse Direction Select	Rescue Mode Enable	0	0	Brake Release Monitor Input 1	(Only Active if P5-04 Brake Release Monitor Enable is set to a value of 2)	Drive Enable	P8-05 (Levelling Speed)
				1	0				P8-06 (High Speed)
				0	1				P8-07 (Intermediate Speed)
				1	1				P8-08 (Inspection Speed)
				0	0				P8-09 (Speed 2)
				1	0				P8-10 (Speed 3)
				0	1				P8-11 (Speed 4)
				1	1				P8-12 (Speed 5)
<p>*Setting 9 above has a different operation (in terms of Motor contactor control) to all other operating modes:</p> <p>When a direction cmd is given the motor contactor relay will Close and normal contactor sequence will begin, however the drive will not start until STO inputs are closed and then Digital Input 8 (Drive Enable signal) has been given</p> <p>Also note in this mode the Auto-tune will only begin when a direction signal has been given (Digital Input 1 or Digital Input 2)</p>									
10	Open Disabled/ Close Forward	Open Disabled/ Close Reverse	0	0	Ok when closed / E-Trip when open or thermistor trip if thermistor function selected in P1-09 Analog Input 2 (DI5) Format	Ok when closed / E-Trip when open or motor contactor feedback trip if P3-02 is set to 1 (Enabled)	Ok when closed / E-Trip when open or Brake resistor monitor feedback trip if P3-06 is set to 1 (Enabled)	Rescue Mode Enable	P8-05 (Levelling Speed)
			1	0					P8-06 (High Speed)
			0	1					P8-07 (Intermediate Speed)
			1	1					P8-08 (Inspection Speed)

**8.10.1. Positive and Negative Logic**

By default, the drive operates in positive logic, P1-43 set to 1 allows negative logic operation (Not STO1 and STO2 inputs)

## 8.11. Control Output Terminal Functions


### 8.11.1. User Relays

The drive has 2 relays, they can be used to switch external resistive loads up to :

Relay 1	8A/250VAC	10A/30VDC
Relay 2	6A/250VAC	6A/30VDC

Relay 2 provides a open or closed contact and has a fixed function of motor brake control.

Relay 1 has both normally open and normally closed contacts available; by default, the function of Relay 1 is to control the motor contactors, if an alternative function is required adjust parameter P1-30 (Relay 1 Function Select).



Parameter Number	Parameter Name	Available Settings			Default	
P1-30	Relay 1 Function Select	<b>Setting</b>	<b>Status/Function Source</b>	<b>Conditions for Status</b>	1	
		0	Drive Enabled (Running)	Logic 1 when Drive is enabled and output stage is on		
		1	Drive Healthy	Logic 1 When no Fault condition exists on the drive. ("inH" is not included as a fault)		
		2	Motor at Zero speed	Logic 1 when motor speed is <=minimum output frequency (P8-02) or <= DC injection at stop speed (P9-15)		
		3	Motor at Target speed	Logic 1 when the output frequency matches the setpoint speed		
		4	Motor Speed > 0	Logic 1 when the motor runs above zero speed		
		5	Motor Speed >= Limit	Logic 1 when the motor speed exceeds the adjustable limit as per set in P1-35 and P1-36		
		6	Motor Current >= Limit	Logic 1 when the motor current exceeds the adjustable limit as per set in P1-35 and P1-36		
		7	Motor Torque >= Limit	Logic when the motor torque exceeds the adjustable limit as per set in P1-35 and P1-36		
		8	STO Status	Logic 1 when both STO inputs are present, and the drive is able to be operated		
		9	Rescue Mode active	Logic 1 when the drive is operating in Rescue Mode		
		10	2nd Anip > limit	Logic when the signal applied to terminal DI5 (Analog Input 2) exceeds the adjustable limit as per set in P1-35 and P1-36		
		Note: When using settings 5, 6, 7, 10, parameters P1-35 and P1-36 must be used together to control the behaviour. The output will switch to Logic 1 when the selected signal exceeds the value programmed in P1-35 and return to Logic 0 when the signal falls below the value in P1-36.				
		11	Motor Contactor control	Used to control the operation of a motor contactor.		
		12	Motor Shorting Contactor control	Used to control the operation of a motor shorting contactor.		
		13	Direction of Travel	Logic 1 when direction down, Logic 0 when stopped or direction up. (Fwd cmd given and speed is positive): UP direction means UP command has been given and motor turns clockwise (Looking at the shaft) and motor speed is positive.		
		14	Service Indicator	Logic 1 when service time interval set in P11-17 has been met		
		15	Brake Control	Used to control the motor brake.		
		16	Door Zone	Logic 1 when motor speed equals (P10-02 Early Door Opening Speed Threshold).		
		17	Light Load direction	Logic 0=Easiest direction is up, Logic 1=easiest direction is downwards.		
		18	Travel limit counter reached	Logic 1 when Travel Direction Change Counter limit P10-05 has been reached.		
19	Set speed and actual speed > P1-42	Logic 1 when the % difference (as per set in Speed following error P1-42) is exceeded between set speed and the actual speed (estimated speed in open loop/encoder speed in closed loop-with encoder)				
20	Alarm	Logic 1 when an alarm is active, e.g P3-07 has been set to 2.				

### 8.11.2. Digital and Analogue Outputs

DA1 and DA2 Outputs can operate as either a Digital Output or an Analog Output, whereas DO3 Output operates as a Digital Output only.

Parameter Number	Parameter Name	Available Settings			Default
P1-15	DA1 Digital Output 1 Function Select				1
P1-22	DA2 Digital Output 2 Function Select				0
P1-28	DO3 Digital Output 2 Function Select				12
		<b>Setting</b>	<b>Status/Function Source</b>	<b>Conditions for Status (Default Logic 1 = 24Vdc output)</b>	
		0	Drive Enabled (Running)	Logic 1 when Drive is enabled and output stage is on	
		1	Drive Healthy	Logic 1 When no Fault condition exists on the drive. ("inH" is not included as a fault)	
		2	Motor at Zero speed	Logic 1 when motor speed is <=/=minimum output frequency (P8-02) or </= DC injection at stop speed (P9-15)	
		3	Motor at Target speed	Logic 1 when the output frequency matches the setpoint frequency	
		4	Motor Speed > 0	Logic 1 when the motor runs above zero speed	
		5	Motor Speed >/= Limit	Logic 1 when the motor speed exceeds the adjustable limit as per detailed in note below.	
		6	Motor Current >/= Limit	Logic 1 when the motor current exceeds the adjustable limit as per detailed in note below.	
		7	Motor Torque >/= Limit	Logic when the motor torque exceeds the adjustable limit as per detailed in note below.	
		8	STO Status	Logic 1 when both STO inputs are present, and the drive is able to be operated	
		9	Rescue Mode active	Logic 1 when the drive is operating in Rescue Mode	
		10	2nd Anip > limit	Logic when the signal applied to the DI5 (Analog Input 2) exceeds the adjustable limit as per detailed in note below.	
		<p>Note: When using settings 5 – 7, 10, parameters P1-31 and P1-32 (For DA1), P1-33 and P1-34 (For DA2), P1-38 and P1-39 (For DO3) must be used together to control the behaviour. e.g the output will switch to Logic 1 when the selected signal exceeds the value programmed in P1-31 (Upper Limit) and return to Logic 0 when the signal falls below the value in P1-32 (Lower Limit).</p>			
		11	Motor Contactor control	Used to control the operation of a motor contactor.	
		12	Motor Shorting Contactor control	Used to control the operation of a motor shorting contactor.	
		13	Direction of Travel	Logic 1 when direction down, Logic 0 when stopped or direction up. (Fwd cmd given and speed is positive): UP direction means UP command has been given and motor turns clockwise (Looking at the shaft) and motor speed is positive.	
		14	Service Indicator	Logic 1 when service time interval as per set in P11-17 has been met	
		15	Brake Control	Used to control the motor brake.	
		16	Door Zone	Logic 1 when motor speed equals (P10-02 Early Door Opening Speed Threshold).	
		17	Light Load direction	Logic 0=Easiest direction is up, Logic 1=easiest direction is downwards.	
		18	Travel limit counter reached	Logic 1 when Travel Direction Change Counter limit P10-05 has been reached.	
		19	Set speed and actual speed > P1-42	Logic 1 when the % difference (as per set in Speed following error P1-42) is exceeded between set speed and the actual speed (estimated speed in open loop/encoder speed in closed loop-with encoder)	
		20	Alarm	Logic 1 when an alarm is active, for example when P3-07 has been set to 2.	

## 9. Using the Keypad


The drive is configured, and its operation monitored via the keypad and display.

### 9.1. Keypad Layout and Function

	NAVIGATE	Used to display real-time information, to access and exit parameter edit mode and to store parameter changes	
	UP	Used to increase parameter values in parameter edit mode	
	DOWN	Used to decrease parameter values in parameter edit mode	
	RESET	Used to reset a tripped drive.	
		Used in Combination with the UP, DOWN and RESET buttons to perform a factory reset of the drive parameters.	

### 9.2. Parameter Map

There are 12 groups of Editable Parameters within the drive, for ease of parameter navigation the groups are ordered in alignment with the order of work when commissioning a typical system.



### 9.3. Changing Parameters

Procedure	Display shows...
Power on Drive	StoP Inhibit
Press and hold the  for >2 seconds	P 1-01
Press the  Key	P 1-02
The  and  can be used to select the desired parameter	P 1-03 etc..
Select the required parameter, e.g. P1-02	P 1-02
Press the  button	0.0
Use  the  and keys to adjust the value, e.g. set to 10	10.0
Press the  key	P 1-02
The parameter value is now adjusted and automatically stored. Press the  key for >2 seconds to return to operating mode	StoP

#### 9.4. Resetting Parameters to Factory Default Settings



Note:

- Parameters cannot be defaulted whilst P11-03=1 (Parameter Access Lock).

#### 9.5. Resetting Parameters to OEM Default Settings

P11-01 (Save user parameters as User default) can be enabled (set to 1) to invoke a parameter save of the current parameter values as the standard defaults for the drive, *U5r-P5* will be shown to indicate a successful save.

The user can recall **User default** settings by following the below procedure.




Note:

- Parameters cannot be defaulted whilst P11-03=1 (Parameter Access Lock).

#### 9.6. Showing Difference from defaults.

Difference from default values can be shown by setting parameter P0-00 (Show Difference from defaults) to a value of 1, once set only the parameters which have been changed by the user will be displayed.

## 9.7. Drive Operating Displays

Display	Status
StoP	Drive mains power applied, but no Enable or Run signal applied
Auto-tH	Motor Autotune in progress. x indicates which autotune is being performed
H H_H	Drive running, display shows output frequency (Hz)
r H_H	Drive running, display shows motor Speed in rpm providing P4-06 (Motor Rated speed) value has been entered, if not entered then this Display status is skipped
A H_H	Drive running, display shows motor current (Amps)
P H_H	Drive Running, display shows motor power (kW)
L H_H	Drive Running, display shows motor speed in linear units (e.g. m/s or ft/s). P3-08 (Sheave diameter), P3-09 (Roping Ratio) , P3-10 (Gear Ratio), P4-06 (Motor rated speed) must be set correctly.
C H_H	Drive Running, display shows customer selected units, see parameters P11-11 and 11-12
UP H_H	When in rescue mode (With encoder) the direction of travel can be displayed, it is assumed that when a run up (forward) command (e.g. terminal 2 closed) is given the motor rotates clockwise (looking at the motor with the sheave facing you).
dn H_H	
EEL-24	Drive mains power not present, external 24 Volt control power supply present only
INH ibt	Output power hardware inhibited, Safe Torque Off function activated. Note: Both STO inputs need to be high to take the drive out of this state, this is normally part of the system safety chain.
	
P-dEF	Parameters reset to factory default settings
U-dEF	Parameters reset to User default settings (P11-01=1)
USB C	Drives is powered from the USB-C port
USB P	Drives is powered from the USB-C port, but data transfer is disabled (P2-13=0)

Whilst the drive is running, the following displays can be selected by briefly pressing the mode button on the drive.



Each press of the mode button will cycle the display through to the next selection.

Fault messages can be found in section 20 Troubleshooting

## 9.8. Elevator Specific Linear Units

The drive provides the user with the option to operate in linear units e.g. m/s, the drive calculates the value internally providing the correct values are entered into the below parameters.

To enable this feature the user must program the following parameters:

- Motor Rated Speed (P4-06)
- Sheave Diameter (P3-08) (<100 drive assumes inches)/(>100 drive assumes mm)
- Roping Ratio (P3-09)
- Gear Ratio for Geared (Induction) systems (P3-10)

**Note: If P4-06 and P3-08 are zero then the function is inactive.**



Once the above parameters are programmed the user can view the real time travel speed by pressing the mode button until “L” is shown in the left side of the display and all speed and jerk parameters will operate in linear units mode.

## 10. First Start-up of Geared (Induction) Motors without an Encoder.

The below procedure illustrates a method for commissioning the drive in a typical elevator application, it is assumed the drive has already been mechanically installed.

### 10.1. Step 1- Wiring Connections.

It is assumed the drive is connected as per Section 8.3 Overall Wiring Diagram and default terminal functions.

### 10.2. Step 2- Pre-Power Checks.

Action/Checks	Additional Information
 <p><b>Do Not Apply Electrical Power Yet!</b></p>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Check that all safety circuits/safety chains are in the correct state, failure to do so could result in damage to the equipment and possible injury or death.</li> <li><input type="checkbox"/> Check that the intended voltage source matches that of the drive voltage rating.</li> <li><input type="checkbox"/> Check that any unexpected movement in the motor will not result in damage to equipment / safety risk to persons.</li> <li><input type="checkbox"/> Check that the elevator controller will not give a start signal to the drive when Electrical power is applied.</li> <li><input type="checkbox"/> Ideally the Lift car should be balanced (i.e. with brakes off the lift car should not naturally move) and with enough shaft headroom to prevent reaching end stops during initial test travels.</li> </ul>
<p><b>Check all necessary electrical connections.</b></p>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Check Electrical Supply cables are connected to the Input power terminals of the drive.</li> <li><input type="checkbox"/> Check Motor Cables are connected to the drive U, V, W terminals (If cables have identification markers connect correct phase sequence).</li> <li><input type="checkbox"/> Check Brake resistor is connected to the "+DC" and "BR" terminals of the drive and that the resistance is higher than the minimum allowable value and resistor is suitably protected from thermal overload.</li> <li><input type="checkbox"/> Check correct control connections are made between the Elevator control panel and the drive. (as detailed in section 8.3 Overall Wiring Diagram and default terminal functions).</li> </ul>

### 10.3. Step 3- Apply Power.

 <b>Apply Electrical Power to the drive</b>	<input type="checkbox"/> Apply rated voltage to the drive.  <input type="checkbox"/> Check that the drive displays <b>Stop</b> or <b>Inhibit</b> .	➤ If <b>Stop</b> or <b>Inhibit</b> is not shown refer to the section 20 Troubleshooting.
---	--	--

### 10.4. Step 4- Motor nameplate data entry.


Action	Additional Information
<b>Select Geared (Induction) motor control</b> <input type="checkbox"/> Set P4-01 to 0	
<b>Enter motor rated voltage (P4-02)</b> <input type="checkbox"/> Enter value into P4-02	Enter Voltage value as shown on the motor nameplate (Volts).
<b>Enter Motor Rated Current (P4-03)</b> <input type="checkbox"/> Enter value into P4-03	Enter Current value as shown on the motor nameplate (Amps).
<b>Enter Motor Rated Frequency (P4-04)</b> <input type="checkbox"/> Enter value into P4-04	Enter Frequency value as shown on the motor nameplate (Hz).
<b>Enter Number of Motor Poles (P4-05)</b> <input type="checkbox"/> Enter value into P4-05	Enter motor pole value as shown on the motor nameplate, if unknown set P4-05 to 0 where the drive will automatically calculate the value providing P4-04 (Motor rated frequency) and P4-06 (Motor rated speed) have been entered correctly.
<b>Enter Motor Rated Speed (P4-06)</b> <input type="checkbox"/> Enter value into P4-06	Enter motor rated speed value as shown on the motor nameplate (rpm).  The drive display will now show motor speed in estimated rpm. All speed related parameters, such as Minimum and Maximum Speed, run Speeds etc. will also be displayed in Rpm.
<b>Enter Motor power factor Cos φ (P4-07)</b> <input type="checkbox"/> Enter value into P4-07	<ul style="list-style-type: none"> <li>Obtained from Motor nameplate.</li> <li>If Motor power factor is unknown leave as default value.</li> </ul> Note: When the motor is running, parameter P0-22 displays the measured power factor value, and this can then be entered into P4-07.
<b>Enter the Maximum speed (P8-01)</b> <input type="checkbox"/> Enter value into P8-01	This is the maximum allowable speed in rpm.

### 10.5. Step 5- Motor Auto-tune.

A Motor Auto-tune must be carried out in order to measure the motor electrical characteristics, brakes will be applied by the drive (unless controlled by other means) during this test.

Action	Additional Information
<input type="checkbox"/> If the motor contactor(s) are controlled by the elevator controller then they should be activated to close so that the motor is electrically connected to the drive, otherwise the "Auto-tune" cannot be carried out. <input type="checkbox"/> If the motor contactor(s) are controlled by the drive (connected to relay 1) the motor contactor will automatically be energised when the "Auto-tune" is enabled.	
<input type="checkbox"/> Check Safe Torque off input connections have been made.	 <p>Drive should now show <b>Stop</b> if not see section 20 Troubleshooting.</p> <p>The STO input status can be viewed in parameter P0-03 (0 = Open 1 = Closed)</p>
<input type="checkbox"/> Enable Stationary Motor Auto-tune	<p>Set P4-08 to a <u>1</u></p>  <p>and press on the drive keypad.</p> <ol style="list-style-type: none"> <li>The motor contactors will close (if controlled by the drive "Relay 1").</li> <li>The motor brakes will remain applied. (Relay 2 as default)</li> <li>The display will show <b>Auto-t</b>. (Test procedure may take several seconds to complete). Note : If the drive trips refer to section 20 Troubleshooting.</li> <li>The motor contactors will open once the test has completed. (Relay 1 controlled by default)</li> </ol> <p>Once the Auto-tune is completed P4-08 will return to 0 and the display will show <b>Stop</b> (P4-24 thru to P4-28 will be populated).</p> <p><b>Note:</b> Motor Auto-tune will need to be repeated if the motor, motor cables, motor parameters or drive control mode is changed in P4-01.</p>

### 10.6. Step 6 – Running the Elevator

Action	Guidance
<input type="checkbox"/> Check for Suitable travel headroom	Ideally the Lift car should be balanced (i.e. with brakes off, the lift car should not naturally move) and with enough shaft headroom to prevent reaching end stops during initial test travels.
<input type="checkbox"/> Run the elevator at reduced speed.	<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p><input type="checkbox"/> Close ST01 &amp; STO2 inputs and the drive should show <i>Stop</i></p>  </div> <div style="width: 45%; text-align: center;">  </div> </div> <p><input type="checkbox"/> Provide a speed reference to the drive.</p>  <p><input type="checkbox"/> Normally inspection speed is used. If P1-02 is at default value (P1-02=1) then inspection speed is defined in parameter P8-08, in this case inspection speed is selected when DI6 is high.</p> <p><input type="checkbox"/> Provide a run-direction command to the drive.</p>  <p>If the drive trips refer to section 20 Troubleshooting.</p>
<input type="checkbox"/> If no problems are encountered then the lift can now be run normally.	

## 11. First Start-up of Geared (Induction) Motors with an Encoder.

The below procedure illustrates a method for commissioning the drive in a typical elevator application, it is assumed the drive has already been mechanically installed.

### 11.1. Step 1- Wiring Connections.

It is assumed the drive is connected as per Section 8.3 Overall Wiring Diagram and default terminal functions.

### 11.2. Step 2- Pre-Power Checks.

Action/Checks	Additional Information
 <p><b>Do Not Apply Electrical Power Yet!</b></p>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Check that all safety circuits/safety chains are in the correct state, failure to do so could result in damage to the equipment and possible injury or death.</li> <li><input type="checkbox"/> Check that the intended voltage source matches that of the drive voltage rating.</li> <li><input type="checkbox"/> Check that any unexpected movement in the motor will not result in damage to equipment / safety risk to persons.</li> <li><input type="checkbox"/> Check that the elevator controller will not give a start signal to the drive when Electrical power is applied.</li> <li><input type="checkbox"/> Ideally the Lift car should be balanced (i.e. with brakes off the lift car should not naturally move) and with enough shaft headroom to prevent reaching end stops during initial test travels.</li> </ul>
<p><b>Check all necessary electrical connections to the drive.</b></p>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Check Electrical Supply cables are connected to the Input power terminals of the drive.</li> <li><input type="checkbox"/> Check Motor Cables are connected to the drive U, V, W terminals (If cables have identification markers connect correct phase sequence).</li> <li><input type="checkbox"/> Check Brake resistor is connected to the "+DC" and "BR" terminals of the drive and that the resistance is higher than the minimum allowable value and resistor is suitably protected from thermal overload.</li> <li><input type="checkbox"/> Check correct control connections are made between the Elevator control panel and the drive. (as detailed in 0 Overall Wiring Diagram and default terminal functions).</li> <li><input type="checkbox"/> Check encoder module has been installed and the correct connections are made between the drive and the Encoder. (as detailed in section 8.3 Overall Wiring Diagram and default terminal functions).</li> <li><input type="checkbox"/> The encoder module expects that the Encoder A channel leads the B channel when the motor is running clockwise (looking in the direction of the motor shaft), if this is not the case then parameter P6-02 (Encoder feedback direction) can be set to a 1 to change the sequence internally in the drive.</li> </ul>
<p><b>Check all necessary electrical connections to the Encoder Module.</b></p>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Check encoder module has been installed and the correct connections are made between the drive and the Encoder. (as detailed in Section 8.3 Overall Wiring Diagram and default terminal functions)</li> <li><input type="checkbox"/> The encoder module expects that the Encoder A channel leads the B channel when the motor is running clockwise (looking in the direction of the motor shaft), if this is not the case then parameter P6-02 (Encoder feedback direction) can be set to a 1 to change the sequence internally in the drive.</li> </ul>

### 11.3. Step 3- Apply Power.

 <b>Apply Electrical Power to the drive</b>	<input type="checkbox"/> Apply rated voltage to the drive.  <input type="checkbox"/> Check that the drive displays <b>Stop</b> or <b>Inhibit</b> .  <input type="checkbox"/> Check that the Encoder module Top LED light is illuminated Red	<ul style="list-style-type: none"> <li>➤ If <b>Stop</b> or <b>Inhibit</b> is not shown or a red light is shown on the encoder module refer to section 20 Troubleshooting.</li> <li>➤ If there is no red light shown on the encoder module :                     <ul style="list-style-type: none"> <li>○ Check encoder module is pushed fully home.</li> <li>○ Check the encoder wiring is correct.</li> </ul> </li> </ul>
---	---	--



### 11.4. Step 4- Motor nameplate data entry.

Action		Additional Information
<b>Select Geared (Induction) motor control</b>	<input type="checkbox"/> Set P4-01 to 0	
<b>Enter motor rated voltage (P4-02)</b>	<input type="checkbox"/> Enter value into P4-02	Enter Voltage value as shown on the motor nameplate (Volts).
<b>Enter Motor Rated Current (P4-03)</b>	<input type="checkbox"/> Enter value into P4-03	Enter Current value as shown on the motor nameplate (Amps).
<b>Enter Motor Rated Frequency (P4-04)</b>	<input type="checkbox"/> Enter value into P4-04	Enter Frequency value as shown on the motor nameplate (Hz).
<b>Enter Number of Motor Poles (P4-05)</b>	<input type="checkbox"/> Enter value into P4-05	Enter motor pole value as shown on the motor nameplate, if unknown set P4-05 to 0 where the drive will automatically calculate the value providing P4-04 (Motor rated frequency) and P4-06 (Motor rated speed) have been entered correctly.
<b>Enter Motor Rated Speed (P4-06)</b>	<input type="checkbox"/> Enter value into P4-06	Enter motor rated speed value as shown on the motor nameplate (rpm).  The drive display will now show motor speed in estimated rpm. All speed related parameters, such as Minimum and Maximum Speed, run Speeds etc. will also be displayed in Rpm.
<b>Enter Motor power factor Cos φ (P4-07)</b>	<input type="checkbox"/> Enter value into P4-07	<ul style="list-style-type: none"> <li>• Obtained from Motor nameplate.</li> <li>• If Motor power factor is unknown leave as default value.</li> </ul> Note: When the motor is running, parameter P0-22 displays the measured power factor value, and this can then be entered into P4-07.
<b>Enter the Maximum speed (P8-01)</b>	<input type="checkbox"/> Enter value into P8-01	This is the maximum allowable speed in rpm.

### 11.5. Step 5 - Encoder Setup

Action		Additional Information	
<b>Enter Encoder Resolution</b>	<input type="checkbox"/> Enter encoder pulses per revolution into P6-03	Refer to Encoder datasheet or nameplate.	
<b>Select Encoder Type</b>	<input type="checkbox"/> Select the Encoder type in parameter P6-04	<b>P6-04 setting</b>	<b>Encoder Type</b>
		0 (Default)	No Encoder Type Selected
		1	Incremental TTL- Differential (A,/A,B,/B) (RS422)
		2	Incremental HTL-Differential (A,/A,B,/B) (24V)
		5	Incremental TTL- Differential (A,/A,B,/B, Z,/Z) (RS422)
		6	Incremental TTL (A,B)
		7	Incremental TTL (A,B, Z)
		8	Incremental HTL- Differential (A,/A,B,/B, Z/Z) (24V)
		9	Incremental HTL (A,B) (24V)
		10	Incremental HTL (A,B,Z) (24V)


### 11.6. Step 6- Motor Auto-tune.

A Motor Auto-tune must be carried out in order to measure the motor electrical characteristics, brakes will be applied by the drive (unless controlled by other means) during this test.

Action	Additional Information
<p><input type="checkbox"/> If the motor contactor(s) are controlled by the elevator controller then they should be activated to close so that the motor is electrically connected to the drive, otherwise the “Auto-tune” cannot be carried out.</p> <p><input type="checkbox"/> If the motor contactor(s) are controlled by the drive (connected to relay 1) the motor contactor will automatically be energised when the “Auto-tune” is enabled.</p> <p><b>Note :</b> For the motor contactor to close the safety chain will need to be closed.</p>	
<p><input type="checkbox"/> Check Safe Torque off input connections have been made.</p>	<div data-bbox="341 506 699 589" data-label="Diagram"> </div> <p data-bbox="738 479 1422 512">Drive should now show <b>StoP</b> if not see section 20 Troubleshooting.</p> <p data-bbox="738 584 1506 613">The STO input status can be viewed in parameter <b>P0-03</b>. (0 = Open 1 = Closed)</p>
<p><input type="checkbox"/> Enable Motor Auto-tune</p>	<p data-bbox="336 775 632 804">Set <b>P4-08</b> to a <u>1</u> and press the</p> <div data-bbox="341 804 493 882" data-label="Image"> <p data-bbox="421 857 493 882">button.</p> </div> <ol data-bbox="738 640 1469 851" style="list-style-type: none"> <li>The motor contactors will close (if controlled by the drive “Relay 1”).</li> <li>The motor brakes will remain applied. (Relay 2)</li> <li>The display will show <b>Auto-t</b>. (Test procedure may take several minutes to complete). Note : If the drive trips refer to section 20 Troubleshooting.</li> <li>The motor contactors will open once the test has completed. (Relay 1 controlled by default)</li> </ol> <p data-bbox="738 898 1474 963">Once the Auto-tune is completed <b>P4-08</b> will return to 0 and the display will show <b>StoP</b> (<b>P4-24</b> thru to <b>P4-28</b> will be populated).</p> <p data-bbox="738 981 1485 1034"><b>Note:</b> Motor Auto-tune will need to be repeated if the motor, motor cables, motor parameters or drive control mode is changed in <b>P4-01</b>.</p>

### 11.7. Step 7 – Running the Elevator

Action	Guidance
<p><input type="checkbox"/> Check for Suitable travel headroom</p>	<p>Ideally the Lift car should be balanced (i.e. with brakes off, the lift car should not naturally move) and with enough shaft headroom to prevent reaching end stops during initial test travels.</p>
<p><input type="checkbox"/> Run the elevator at reduced speed.</p>	<p data-bbox="298 1330 863 1386"><input type="checkbox"/> Close <b>STO1</b> &amp; <b>STO2</b> inputs and the drive should show <b>StoP</b></p> <div data-bbox="308 1413 798 1525" data-label="Diagram"> </div> <div data-bbox="916 1323 1129 1532" data-label="Image"> </div> <p data-bbox="298 1563 730 1592"><input type="checkbox"/> Provide a speed reference to the drive.</p> <div data-bbox="308 1592 836 1720" data-label="Diagram"> </div> <p data-bbox="298 1749 1458 1805">Normally inspection speed is used. If <b>P1-02</b> is at default value (<b>P1-02=1</b>) then inspection speed is defined in parameter <b>P8-08</b>, in this case inspection speed is selected when <b>DI6</b> is high.</p> <p data-bbox="298 1872 804 1901"><input type="checkbox"/> Provide a run-direction command to the drive.</p> <div data-bbox="308 1928 826 2040" data-label="Diagram"> </div> <p data-bbox="298 2085 815 2114">If the drive trips refer to section 20 Troubleshooting.</p>

<input type="checkbox"/> <b>Check motor direction and encoder direction is correct.</b>	<input type="checkbox"/> During this check you will need to Navigate between parameters <b>P0-18</b> (Estimated motor speed) and <b>P0-19</b> (Encoder speed). <input type="checkbox"/> Provide a run-direction command to terminal 2 and run at low speed for a short travel e.g. levelling/10% of motor rated speed. <input type="checkbox"/> Check that the value shown in <b>P0-18</b> is positive in the Up direction and Negative in the down direction, if it is not then set <b>P11-09</b> to 1. <input type="checkbox"/> Check that the value in <b>P0-18</b> and <b>P0-19</b> match in sign.	<input type="checkbox"/> If the drive shows <i>inhibit</i> when a run-direction command is given ensure that the Safe Torque off inputs are made.  <p>The diagram shows a 'Safety Chain' block with two outputs labeled 'Drive Inhibit'. These outputs connect to three terminals on the right: ST01, ST02, and 24V. Each terminal has a screw terminal symbol.</p>
<input type="checkbox"/> <b>Enable Encoder</b>	Set <b>P6-05</b> to 1	Enables Encoder Feedback
<input type="checkbox"/> <b>If no problems are encountered then the lift can now be run normally.</b>		

## 12.Start-up of Gearless (Permanent Magnet) Motor.

The below procedure illustrates a method for commissioning the drive in a typical elevator application, it is assumed the drive has already been mechanically installed.

### 12.1. Step 1- Wiring Connections.

It is assumed the drive is connected as per Section 8.3 Overall Wiring Diagram and default terminal functions.

### 12.2. Step 2- Pre-Power Checks.

Action/Checks	Additional Information
 <p><b>Do Not Apply Electrical Power Yet!</b></p>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Check that all safety circuits/safety chains are in the correct state, failure to do so could result in damage to the equipment and possible injury or death.</li> <li><input type="checkbox"/> Check that the intended voltage source matches that of the drive voltage rating.</li> <li><input type="checkbox"/> Check that any unexpected movement in the motor will not result in damage to equipment / safety risk to persons.</li> <li><input type="checkbox"/> Check that the elevator controller will not give a start signal to the drive when Electrical power is applied.</li> <li><input type="checkbox"/> Ideally the Lift car should be balanced (i.e. with brakes off the lift car should not naturally move) and with enough shaft headroom to prevent reaching end stops during initial test travels.</li> </ul>
<p><b>Check all necessary electrical connections.</b></p>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Check Electrical Supply cables are connected to the Input power terminals of the drive.</li> <li><input type="checkbox"/> Check Motor Cables are connected to the drive U, V, W terminals (If cables have identification markers connect correct phase sequence).</li> <li><input type="checkbox"/> Check Brake resistor is connected to the “+DC” and “BR” terminals of the drive and that the resistance is higher than the minimum allowable value and resistor is suitably protected from thermal overload.</li> <li><input type="checkbox"/> Check correct control connections are made between the Elevator control panel and the drive. (as detailed in Section 8.3 Overall Wiring Diagram and default terminal functions).</li> <li><input type="checkbox"/> Check encoder module has been installed and the correct connections are made between the drive and the Encoder.</li> </ul>

### 12.3. Step 3- Apply Power.

 <p><b>Apply Electrical Power to the drive</b></p>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Apply rated voltage to the drive.</li> <li><input type="checkbox"/> Check that the drive displays <b>StoP</b> or <b>i n h i b i t</b>.</li> <li><input type="checkbox"/> Check that the Encoder module (Optional) left hand LED light is illuminated Red</li> </ul>	<ul style="list-style-type: none"> <li>➤ If <b>StoP</b> or <b>i n h i b i t</b> is not shown or a red light is shown on the encoder module refer to section 20 Troubleshooting.</li> <li>➤ If there is no green light shown on the encoder module :                             <ul style="list-style-type: none"> <li>○ Check encoder module is pushed fully home.</li> <li>○ Check the encoder wiring is correct.</li> </ul> </li> </ul> 
---	---	--

### 12.4. Step 4- Motor nameplate data entry.


Action		Additional Information
Select Gearless (Permanent Magnet) motor control mode. (P4-01)	<input type="checkbox"/> Set P4-01 to 3	Both IPM and SPM type motors are supported.
Enter Motor Rated Current (P4-03)	<input type="checkbox"/> Enter motor rated current into P4-03	Obtained from Motor nameplate (Amps).
Enter Motor Rated Frequency (P4-04)	<input type="checkbox"/> Enter motor rated frequency into P4-04	Obtained from Motor nameplate (Hz).
Enter Number of Motor Poles (P4-05)	<input type="checkbox"/> Enter value into P4-05	Enter motor pole value as shown on the motor nameplate, if unknown set P4-05 to 0 where the drive will automatically calculate the value providing P4-04 (Motor rated frequency) and P4-06 (Motor rated speed) have been entered correctly.
Enter Motor Rated Speed (P4-06)	<input type="checkbox"/> Enter motor rated speed into P4-06	Obtained from Motor nameplate. If not available it can be calculated: Motor rated frequency*120/motor poles.
Enter the Maximum speed (P8-01)	<input type="checkbox"/> Enter value into P8-01	This is the maximum allowable speed.

### 12.5. Step 5- Encoder setup.



Action		Additional Information
Select absolute encoder type (Endat or SinCos) (P6-04)	<input type="checkbox"/> Select setting 3 for SinCos Encoder. ERN 1387 <input type="checkbox"/> Select setting 4 for Endat Encoder. ECN1313, ECN113, ECN413, ECN1325, ECN125, ECN425.	It is assumed Encoder incremental signals (A, A/ B, B/) are connected, if not then you can set P6-04 to 11 Instead.
Enable the Encoder (P6-05)	<input type="checkbox"/> Set P6-05 to 1	Enables Encoder Feedback and puts the drive into closed loop operation.

### 12.6. Step 6- Motor Auto-tune.

A Motor Auto-tune must be carried out in order to measure the motor electrical characteristics, during the Auto-tune test the motor brakes will be applied by the drive (assuming they are controlled by Relay 2 on the drive).


Action		Additional Information
<input type="checkbox"/> If the motor contactor(s) are controlled by the elevator controller then they should be activated to close so that the motor is electrically connected to the drive, otherwise the "Auto-tune" cannot be carried out. <input type="checkbox"/> If the motor contactor(s) are controlled by the drive (connected to relay 1) the motor contactor will automatically be energised when the "Auto-tune" is enabled. <b>Note:</b> For the motor contactor to close the safety chain will need to be closed.		
<input type="checkbox"/> Check Safe Torque off inputs have been made.		Drive should now show <b>STOP</b> , if not see section 20 Troubleshooting.  The STO input status can be viewed in parameter P0-03.(0 = Open 1 = Closed)
Enable Motor Auto-tune (Motor Electrical measurement & Encoder offset measurement)	<input type="checkbox"/> Set P4-08 to a <u>3</u> and press the  button.	<ol style="list-style-type: none"> <li>The motor contactors will close (if controlled by the drive "Relay 1"), if not by Relay 1 then they need to be closed.</li> <li>The motor brakes will remain applied. (Relay 2)</li> <li>The display will show <b>Auto-t</b>. (Test procedure may take several minutes to complete). Note : If the drive trips refer to section 20 Troubleshooting.</li> <li>The motor contactors will open once the test has completed. (Relay 1 controlled by default)</li> </ol> Once the Auto-tune is completed P4-08 will return to 0 and the display will show <b>STOP</b> (P4-24, P4-26, P4-27 and P6-09 will be populated).  If the drive trips on <b>REF-05</b> it means that the motor has surface mount magnets, in this case set P4-08 to a 4 for the drive to perform an alternative Encoder offset measurement.  <b>Note:</b> <ul style="list-style-type: none"> <li>Motor Auto-tune will need to be repeated if the Encoder, motor, motor cables, motor parameters or drive control mode is changed in P4-01.</li> <li>Encoder offset value (P6-09) will be wrong if the motor poles (P4-05) has been set incorrectly.</li> </ul>

## 12.7. Step 7 – Running the Elevator

Action	Guidance
<input type="checkbox"/> Check for Suitable travel headroom	Ideally the Lift car should be balanced (i.e. with brakes off, the lift car should not naturally move) and with enough shaft headroom to prevent reaching end stops during initial test travels.
<input type="checkbox"/> Run the elevator at reduced speed.	<input type="checkbox"/> Close ST01 & ST02 inputs and the drive should show $SEOP$ 
	<input type="checkbox"/> Provide a speed reference to the drive.  Normally inspection speed is used. If P1-02 is at default value (P1-02=1) then inspection speed is defined in parameter P8-08, in this case inspection speed is selected when DI6 is high.
	<input type="checkbox"/> Provide a run-direction command to the drive. 
	If the drive trips refer to section 20 Troubleshooting.
<input type="checkbox"/> If no problems are encountered then the lift can now be run normally.	

# 13.Travel Curve Adjustment

## 13.1. Travel Curve Sequence




Note : The jerk parameters will have an effect on the overall ramp times in the following way :

$$\text{Total Acceleration Ramp time} = P8-03 (\text{Acceleration ramp time}) + (P9-01+P9-02 / 2)$$

Operating Mode	P4-01	P6-05	Sheave Locking during start	Sheave Locking During Stop
Geared (Induction) Motors without an Encoder	0	0	P9-11 (DC Injection time at start) P9-12 (DC Injection current at start)	P9-13 (DC Injection time at stop) P9-14 (DC Injection current at stop) P9-15 (DC Injection speed at stop)
Geared (Induction) Motors with Encoder	0	1	P9-16 (Rollback Control P-Gain at start) P9-17 (Rollback Control I-Gain at start) P9-18 (Rollback Control activation pulses)	P9-20 (Rollback Control P-Gain at stop) P9-21 (Rollback Control I-Gain at stop)
Gearless (Permanent Magnet) Motor	3	1	P9-16 (Rollback Control P-Gain at start) P9-17 (Rollback Control I-Gain at start) P9-18 (Rollback Control activation pulses)	P9-20 (Rollback Control P-Gain at stop) P9-21 (Rollback Control I-Gain at stop)

### 13.2. Smooth Start Function

The smooth start function can also help in some cases of rollback, for example in applications with high stiction, in this mode the motor is run at a speed that should be set just above 0 so that it overcomes the stiction before accelerating away towards high speed.




### 13.3. Speed Loop Gains

The setting of the speed loop gains defines how closely the actual motor speed follows the given speed reference; in the case of an Elevator the correct setting of the speed loop gains is critical in order to provide optimum comfort levels.

The speed loop gains are available in all motor operating modes except "Enhanced V/F IM Speed Control mode" (P4-01=2).

In general, the default speed loop gains should provide a good starting point.

Different speed loop gains are available for different parts of the travel profile as shown in the diagram below, noting that from default the drive will operate with only the run gains (P9-27 and P9-28), to utilise the full set of speed loop gains set P9-25/P9-32 >0.



## 14. Comfort Optimisation

The tables below shows the relevant parameters for adjusting the comfort level throughout the travel curve, noting that the parameters maybe different depending on if the system is geared with or without an encoder or gearless.

**Key for Motor Type :** GD = Geared without Encoder, GD+E = Geared with Encoder, GL = Gearless.  
 √ = Relevant with this Motor Type X = Not Relevant with this Motor Type

Problem	Motor Type			Solutions					
	GD	GD+E	GL						
Starting Comfort	Rollback at start.	√	√	√	<b>Tip: Parameter P0-17 can be monitored to show the rollback error after each run.</b> Check Motor parameters match the motor nameplate data: <input type="checkbox"/> For Geared system P4-01 = 0, For Gearless system P4-01 = 3 <input type="checkbox"/> Motor rated voltage (P4-02) <input type="checkbox"/> Motor Rated Current (P4-03) <input type="checkbox"/> Motor Rated Frequency (P4-04) <input type="checkbox"/> Number of Motor Poles (P4-05), set to 0 if unknown. <input type="checkbox"/> Motor Rated Speed (P4-06)				
					√	√	X	<input type="checkbox"/> Motor power factor Cos $\phi$ (P4-07)	
					X	√	√	<input type="checkbox"/> Has Encoder been enabled and setup? <input type="checkbox"/> If no Set P6-05 to a <u>1</u> , set encoder Pulses Per Revolution in P6-03 and set encoder type in P6-04.	
					√	√	X	<input type="checkbox"/> Has Motor auto-tune been performed? <input type="checkbox"/> If no Set P4-08 to a <u>1</u>	
					X	X	√	<input type="checkbox"/> Has Motor auto-tune and Encoder Offset test been performed? <input type="checkbox"/> If no Set P4-08 to a <u>3</u>	
					√	√	√	<input type="checkbox"/> Ensure motor contactor is closing before the drive output is enabled. <input type="checkbox"/> Increase P3-01 (Motor Contactor Closing time)	
					√	√	√	<input type="checkbox"/> Increase brake release time. <input type="checkbox"/> P5-01 (brake release time) If the time is set too long it may not be acceptable in the application	
					√	X	X	<input type="checkbox"/> Adjust DC Injection parameters: Increase P9-12 (DC Injection Current at Start) in steps of 10%, whilst ensuring time set in P9-11 (DC Injection Time at Start) is not too long. <input type="checkbox"/> P9-12 (DC Injection Current at Start) <input type="checkbox"/> P9-11 (DC Injection Time at Start)	
					X	√	√	<input type="checkbox"/> Adjust Rollback Control Gain parameters:  Increase P9-16 (Rollback Control P-Gain at start) in steps of 20% and decrease the value in P9-18 (Rollback Control Activation Pulses).  <b>Tip :</b> <b>The longer the time set in P5-01 (Brake Release time) the more responsive P9-16 will be.</b> <b>P9-18 Determines the movement of the motors shaft (as measured by the encoder) before the rollback function activates</b>	The correct setting of P5-01, P9-16, P9-18 are those which result in no rollback under all load conditions, and with no vibration or jerk when the motor brakes lift/car moves away from the floor.

**Key for Motor Type :** GD = Geared without Encoder, GD+E = Geared with Encoder, GL = Gearless.

√ = Relevant with this Motor Type    X = Not Relevant with this Motor Type

Problem		Motor Type			Solutions
		GD	GD+E	GL	
Starting Comfort	Jerk during Start	√	√	√	<input type="checkbox"/> Parameter <b>P5-01</b> defines the actuation time of the motor brakes, generally the default value (0.20 sec) is suitable for most situations, if there is a jerk felt during acceleration after brake release then reduce <b>P5-01</b> .
		√	√	√	<input type="checkbox"/> Increasing the value of <b>P9-01</b> (Acceleration Start Jerk) can help reduce start jerks.
		√	X	X	<input type="checkbox"/> Try Increasing <b>P9-11</b> (DC Injection Time at Start).
		√	√	√	<input type="checkbox"/> If jerk is felt after brake is released try adjusting speed loop gains, generally <b>P9-23</b> (Speed Loop Proportional Gain at start) is increased.
		√	√	√	<input type="checkbox"/> Also see "Rollback at start" above.
		√	X	X	<input type="checkbox"/> Use Smooth Start function, See Section 13.2

Problem		Motor Type			Solutions	
		GD	GD+E	GL		
Travel Comfort during acceleration and High Speed.	Vibration at High speed	√	√	√	<input type="checkbox"/> Check there are no mechanical problems.	
		√	√	√	<input type="checkbox"/> Check Motor parameters match the motor nameplate data: <input type="checkbox"/> For Geared system <b>P4-01</b> = 0, For Gearless system <b>P4-01</b> = 3 <input type="checkbox"/> Motor rated voltage ( <b>P4-02</b> ) <input type="checkbox"/> Motor Rated Current ( <b>P4-03</b> ) <input type="checkbox"/> Motor Rated Frequency ( <b>P4-04</b> ) <input type="checkbox"/> Number of Motor Poles ( <b>P4-05</b> ), set to 0 if unknown. <input type="checkbox"/> Motor Rated Speed ( <b>P4-06</b> )	
		√	√	X	<input type="checkbox"/> Motor power factor Cos $\phi$ ( <b>P4-07</b> )	
		X	√	√	<input type="checkbox"/> Has Encoder been enabled and setup?	<input type="checkbox"/> If no Set <b>P6-05</b> to a <u>1</u> , set encoder Pulses Per Revolution in <b>P6-03</b> and set encoder type in <b>P6-04</b> .
		√	√	X	<input type="checkbox"/> Has Motor auto-tune been performed?	<input type="checkbox"/> If no Set <b>P4-08</b> to a <u>1</u>
		X	X	√	<input type="checkbox"/> Has Motor auto-tune and Encoder Offset test been performed?	<input type="checkbox"/> If no Set <b>P4-08</b> to a <u>3</u>
		√	√	√	<input type="checkbox"/> Reduce <b>P9-27</b> (Speed Loop proportional gain during run) and Increase <b>P9-28</b> (Speed loop integral gain during run)	
		√	√	√	<input type="checkbox"/> Increase Speed Error deadband	
		X	√	√	<input type="checkbox"/> Increase Encoder filter <b>P6-07</b>	

Problem		Motor Type			Solutions
		GD	GD+E	GL	
Travel Comfort during acceleration and High Speed.	Jerk as high speed is reached	√	√	√	<input type="checkbox"/> Increase <b>P9-02</b> (Acceleration end Jerk) <input type="checkbox"/> Increase <b>P9-27</b> (Speed Loop proportional gain during run) and reduce <b>P9-28</b> (Speed loop integral gain during run).
	Travel speeds different between up and down direction	√	X	X	<input type="checkbox"/> Adjust <b>P4-20</b> (Slip Compensation Gain in Motoring Mode) & <b>P4-21</b> (Slip Compensation Gain in Regenerating Mode) until the motor speed is the same in both directions

Key for Motor Type : GD = Geared without Encoder,    GD+E = Geared with Encoder,    GL = Gearless.

√ = Relevant with this Motor Type    X = Not Relevant with this Motor Type

Problem		Motor Type			Solutions
		GD	GD+E	GL	
Travel Comfort at Levelling speed/Low speed	Vibration at low speed	√	√	√	<input type="checkbox"/> Check there are no mechanical problems.
		√	√	√	<input type="checkbox"/> Confirm that the drive is not operating in current limit ( <b>OLd</b> on Display), if it is reduce load and cabin balancing.
		√	√	√	Check Motor parameters match the motor nameplate data: <input type="checkbox"/> For Geared system <b>P4-01</b> = 0, For Gearless system <b>P4-01</b> = 3 <input type="checkbox"/> Motor rated voltage ( <b>P4-02</b> ) <input type="checkbox"/> Motor Rated Current ( <b>P4-03</b> ) <input type="checkbox"/> Motor Rated Frequency ( <b>P4-04</b> ) <input type="checkbox"/> Number of Motor Poles ( <b>P4-05</b> ), set to 0 if unknown. <input type="checkbox"/> Motor Rated Speed ( <b>P4-06</b> )
		√	√	X	<input type="checkbox"/> Motor power factor Cos $\phi$ ( <b>P4-07</b> )
		X	√	√	<input type="checkbox"/> Has Encoder been enabled and setup? <input type="checkbox"/> If no Set <b>P6-05</b> to a <u>1</u> , set encoder Pulses Per Revolution in <b>P6-03</b> and set encoder type in <b>P6-04</b> .
		√	√	X	<input type="checkbox"/> Has Motor auto-tune been performed? <input type="checkbox"/> If no Set <b>P4-08</b> to a <u>1</u>
		X	X	√	<input type="checkbox"/> Has Motor auto-tune and Encoder Offset test been performed? <input type="checkbox"/> If no Set <b>P4-08</b> to a <u>3</u>
		√	√	√	If it is found that the travel comfort is good at high speed but poor at Levelling speed then the low speed gains can be utilised. <input type="checkbox"/> If low speed gains ( <b>P9-30</b> & <b>P9-31</b> ) are being used then reduce <b>P9-30</b> (Low speed P-gain) and Increase <b>P9-31</b> (Low speed I-gain) <input type="checkbox"/> If low speed gains ( <b>P9-30</b> & <b>P9-31</b> ) are not being used then reduce <b>P9-27</b> (Speed Loop proportional gain during run) and Increase <b>P9-28</b> (Speed loop integral gain during run)
		√	√	√	<input type="checkbox"/> Increase Speed Error deadband
		X	√	√	<input type="checkbox"/> Increase Encoder filter <b>P6-07</b>

Problem		Motor Type			Solutions
		GD	GD+E	GL	
Stopping Comfort	Bump felt when stopping	√	√	√	<input type="checkbox"/> Ensure motor contactor is not opening before the drive output is disabled/Brake applied, if controlled by the drive try increasing <b>P3-01</b> (Motor Contactor Closing time). <input type="checkbox"/> Increase <b>P9-22</b> (Zero speed holding time on disable). <input type="checkbox"/> If a brake apply speed ( <b>P5-03</b> ) has been set reduce the value.
	Motor is pulled in the opposite direction during stopping (overhauling effect of the load)	√	√	√	<input type="checkbox"/> Increase <b>P9-27</b> (Run speed P-gain) or <b>P9-30</b> (Low speed P-gain) if low speed gains are being used.
		√	X	X	Adjust DC Injection during stop parameters: <input type="checkbox"/> <b>P9-13</b> (DC Injection time at stop), <b>P9-14</b> (DC Injection Current at Stop), <b>P9-15</b> (DC Injection speed at stop).
		X	√	√	Adjust Rollback Control Gains during stop parameters: <input type="checkbox"/> <b>P9-20</b> (Rollback Control P-Gain at stop), <b>P9-21</b> (Rollback Control i-Gain at stop).
		X	√	√	<input type="checkbox"/> Check <b>P4-17</b> (Torque reduction during stopping) is not set too high resulting in torque loss prior to stopping.
		√	√	√	Increase Brake Apply speed in parameter in <b>P5-03</b> .
	Noise when the motor brake applies	X	√	√	Decrease <b>P4-17</b> (Torque reduction during stopping), parameter <b>P9-22</b> (Zero speed holding time on disable) can also be increased to give further improvement.

**Key for Motor Type :** GD = Geared without Encoder, GD+E = Geared with Encoder, GL = Gearless.  
 ✓ = Relevant with this Motor Type X = Not Relevant with this Motor Type

Problem		Motor Type			Solutions
		GD	GD+E	GL	
Floor Level Accuracy	Car not reaching floor	✓	✓	✓	<input type="checkbox"/> Confirm that the drive is not operating in current limit ( <b>OverC</b> on Display) if it is then reduce load and cabin balancing.
		✓	✓	✓	<input type="checkbox"/> Increase P8-05 (levelling speed)/ P9-07 (Stopping jerk)
		✓	X	X	<input type="checkbox"/> Decrease DC injection speed at stop P9-15
		✓	✓	✓	<input type="checkbox"/> Ensure speed loop gains are optimally tuned so that the speed following error is minimised Increase P9-27 (Run speed P-gain) and reduce P9-28 (Run speed I-gain) or if using the low speed gains increase P9-30 (Low speed P-gain) and reduce P9-31 (Low speed I-gain).
	Car over-shooting floor	✓	✓	✓	<input type="checkbox"/> Decrease P8-05 (levelling speed)/ P9-07 (Stopping jerk).
		✓	✓	✓	<input type="checkbox"/> Increase P8-05 (levelling speed)/ P9-07 (Stopping jerk)
		✓	✓	✓	<input type="checkbox"/> Increase Brake Apply speed in parameter in P5-03.
		✓	X	X	<input type="checkbox"/> Increase DC injection speed at stop P9-15
		✓	✓	✓	<input type="checkbox"/> Ensure speed loop gains are optimally tuned so that the speed following error is minimised Increase P9-27 (Run speed P-gain) and reduce P9-28 (Run speed I-gain) or if using the low-speed gains increase P9-30 (Low speed P-gain) and reduce P9-31 (Low speed I-gain).

## 15.Parameter Group 0 – Monitoring Parameters

Parameter Number	Parameter Description	Units											
P0-00	<b>Keypad Parameter Display Mode</b>												
	This parameter allows the user to see only the parameters that have been set different to defaults. 0 = Show all Parameters (Noting that the setting of parameter P11-04 limits the parameter groups which are shown) 1 = Show Only parameters that are different from Factory defaults. 2 = Show Only parameters that are different from User defaults.												
P0-01	<b>Digital Input 1 to 5 Status</b>	-											
	Displays the status of the drive digital input terminals 1 to 5  <table border="1"> <thead> <tr> <th>Display value</th> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> </tr> <tr> <th>Input Terminal</th> <td>DI1 status</td> <td>DI2 status</td> <td>DI3 status</td> <td>DI4 status</td> <td>DI5 status</td> </tr> </thead> </table> 1 = Input Active 0 = Input InActive	Display value	<input type="checkbox"/>	Input Terminal	DI1 status	DI2 status	DI3 status	DI4 status	DI5 status				
Display value	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>								
Input Terminal	DI1 status	DI2 status	DI3 status	DI4 status	DI5 status								
P0-02	<b>Digital Input 6 to 10 Status</b>	-											
	Displays the status of the drive digital input terminals 6 to 8 and Auxiliary inputs available on the universal encoder module  <table border="1"> <thead> <tr> <th>Display value</th> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> </tr> <tr> <th>Input Terminal</th> <td>DI6 status</td> <td>DI7 status</td> <td>DI8 status</td> <td>*Daux 1 Input Status</td> <td>*Daux 2 Input Status</td> </tr> </thead> </table> *Daux are the auxiliary inputs on the universal encoder module  1 = Input Active 0 = Input InActive	Display value	<input type="checkbox"/>	Input Terminal	DI6 status	DI7 status	DI8 status	*Daux 1 Input Status	*Daux 2 Input Status				
Display value	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>								
Input Terminal	DI6 status	DI7 status	DI8 status	*Daux 1 Input Status	*Daux 2 Input Status								
P0-03	<b>STO Input Status</b>	-											
	Displays the status of the Safe Torque Inputs. Value Displayed:  <table border="1"> <thead> <tr> <th>Display value</th> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> </tr> <tr> <th>Input Terminal</th> <td>STO1</td> <td>STO2</td> </tr> </thead> </table> 1 = Input Active 0 = Input InActive	Display value	<input type="checkbox"/>	<input type="checkbox"/>	Input Terminal	STO1	STO2						
Display value	<input type="checkbox"/>	<input type="checkbox"/>											
Input Terminal	STO1	STO2											
P0-04	<b>Relay 1 Status</b>	-											
	Displays the status of Relay 1  <table border="1"> <thead> <tr> <th>Display value</th> <td><input type="checkbox"/></td> </tr> <tr> <th>Output Terminal</th> <td>Relay 1 Status</td> </tr> </thead> </table> 0 = Relay Open 1 = Relay Closed	Display value	<input type="checkbox"/>	Output Terminal	Relay 1 Status								
Display value	<input type="checkbox"/>												
Output Terminal	Relay 1 Status												
P0-05	<b>Relay 2 Status</b>	-											
	Displays the status of Relay 2  <table border="1"> <thead> <tr> <th>Display value</th> <td><input type="checkbox"/></td> </tr> <tr> <th>Output Terminal</th> <td>Relay 2 Status</td> </tr> </thead> </table> 0 = Relay Open 1 = Relay Closed	Display value	<input type="checkbox"/>	Output Terminal	Relay 2 Status								
Display value	<input type="checkbox"/>												
Output Terminal	Relay 2 Status												
P0-06	<b>Digital Output Status</b>	-											
	Displays the status of the drive digital Outputs  <table border="1"> <thead> <tr> <th>Display value</th> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> </tr> <tr> <th>Output Terminal</th> <td>DA1</td> <td>DA2</td> <td>DO3</td> </tr> </thead> </table> 0 = Digital Output InActive 1 = Digital Output Active	Display value	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Output Terminal	DA1	DA2	DO3				
Display value	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>										
Output Terminal	DA1	DA2	DO3										

Parameter Number	Parameter Description	Units											
P0-07	<b>Analog Output 1 Value</b>	0.0V – 10.0V (Voltage Mode)  0.0 -20mA (Current mode)											
	Shows the voltage/Current output value from Analog output 1(DA1) after scaling and offsets have been applied.												
	<b>Parameter &gt;</b>	<table border="1"> <thead> <tr> <th>P1-14 DA1 Output 1 Type</th> <th>P1-18 DA1 Output 1 Format</th> <th>P0-07 Display Value</th> </tr> </thead> <tbody> <tr> <td>0 (Digital Output)</td> <td>N/A</td> <td>0.0 (Output off) 0.1 (Output On)</td> </tr> <tr> <td rowspan="2">1 (Analog Output)</td> <td>U 0-10, U 10-0</td> <td>Value in Volts</td> </tr> <tr> <td>A 0-20, A 20-0, A 4-20, A 20-4</td> <td>Value in mA</td> </tr> </tbody> </table>	P1-14 DA1 Output 1 Type	P1-18 DA1 Output 1 Format	P0-07 Display Value	0 (Digital Output)	N/A	0.0 (Output off) 0.1 (Output On)	1 (Analog Output)	U 0-10, U 10-0	Value in Volts	A 0-20, A 20-0, A 4-20, A 20-4	Value in mA
	P1-14 DA1 Output 1 Type	P1-18 DA1 Output 1 Format	P0-07 Display Value										
0 (Digital Output)	N/A	0.0 (Output off) 0.1 (Output On)											
1 (Analog Output)	U 0-10, U 10-0	Value in Volts											
	A 0-20, A 20-0, A 4-20, A 20-4	Value in mA											
<b>Setting &gt;</b>													
P0-08	<b>Analog Output 2 Value</b>	0.0V – 10.0V (Voltage Mode)  0-20mA (Current mode)											
	Shows the voltage/Current output value from Analog output 2 after scaling and offsets have been applied.												
	<b>Parameter &gt;</b>	<table border="1"> <thead> <tr> <th>P1-21 DA2 Output 1 (Terminal 11) Type</th> <th>P1-25 DA2 Output 1 (Terminal 11) Format</th> <th>P0-08 Display Value</th> </tr> </thead> <tbody> <tr> <td>0 (Digital Output)</td> <td>N/A</td> <td>1.0 (Output off) 0.1 (Output On)</td> </tr> <tr> <td rowspan="2">1 (Analog Output)</td> <td>U 0-10, U 10-0</td> <td>Value in Volts</td> </tr> <tr> <td>A 0-20, A 20-0, A 4-20, A 20-4</td> <td>Value in mA</td> </tr> </tbody> </table>	P1-21 DA2 Output 1 (Terminal 11) Type	P1-25 DA2 Output 1 (Terminal 11) Format	P0-08 Display Value	0 (Digital Output)	N/A	1.0 (Output off) 0.1 (Output On)	1 (Analog Output)	U 0-10, U 10-0	Value in Volts	A 0-20, A 20-0, A 4-20, A 20-4	Value in mA
	P1-21 DA2 Output 1 (Terminal 11) Type	P1-25 DA2 Output 1 (Terminal 11) Format	P0-08 Display Value										
0 (Digital Output)	N/A	1.0 (Output off) 0.1 (Output On)											
1 (Analog Output)	U 0-10, U 10-0	Value in Volts											
	A 0-20, A 20-0, A 4-20, A 20-4	Value in mA											
<b>Setting &gt;</b>													
P0-09	<b>Motor contactor measured opening time</b>												
P0-10	<b>Motor contactor measured Closing time</b>												
P0-11	<b>Brake Release measured opening time</b>												
P0-12	<b>Brake Apply measured Closing time</b>												
P0-13	<b>Pre-Ramp Speed Controller Reference</b>	Hz/RPM/Linear											
Displays the set point reference input applied to the drive internal speed controller													
P0-14	<b>Speed Reference via Fieldbus Network</b>	Hz/RPM/Linear											
Displays the setpoint being received by the drive from the currently active Fieldbus interface.													
P0-15	<b>Post-Ramp Speed Controller Reference</b>	Hz/RPM/Linear											
Displays the post-ramp set-point reference applied to the drive internal speed controller													
P0-16	<b>Speed Error</b>	Hz/RPM/Linear											
Speed Error between the post-ramp speed reference (P0-15) and.. Rotor speed (P0-18) with Encoder disabled Encoder speed (P0-19) with Encoder Enabled.													
P0-17	<b>Rollback Error (Encoder Modes only)</b>	Pulses											
Displays the rollback count													
P0-18	<b>Rotor Speed (Estimated or Measured)</b>	Hz/RPM/Linear											
This parameter displays either the estimated rotor speed of the motor, if no encoder feedback is present, or the measured rotor speed if an optional Encoder Feedback Interface Option is fitted.													
P0-19	<b>Encoder Feedback Speed</b>	Hz/RPM/Linear											
Displays the Actual Encoder Feedback speed.													
P0-20	<b>Real-time Encoder offset Value</b>	°											
Live Encoder offset value shown in Degrees (1 degree resolution)													
P0-21	<b>Calculated Slip Speed Value (Enhanced V/F Mode Only)</b>	-											
P0-22	<b>Measured Motor Power Factor</b>												
Real time motor power factor whilst drive is running.													
P0-23	<b>Highest Current During Acceleration</b>												
P0-24	<b>Highest Current During Deceleration</b>												
P0-25	<b>Motor Current</b>	A											

Parameter Number	Parameter Description	Units	
P0-26	<b>Motor Magnetising Current (Id)</b>	A	
	Displays the motor magnetising Current, providing an auto tune has been successfully completed.		
P0-27	<b>Motor Rotor Current (Iq)</b>	A	
	Displays the motor Rotor (torque producing) current, providing an auto tune has been successfully completed.		
P0-28	<b>Output Torque</b>	%	
	Displays the instantaneous output torque level produced by the motor. 0.1% resolution 100% = motor rated torque.		
P0-29	<b>Motor Input Power</b>		
P0-30	<b>Motor Shaft Power</b>		
P0-31	<b>Motor Overload Accumulator (%)</b>	%	
P0-32	<b>Back EMF Measured Value</b>	VAC	
	Ph-Ph back emf measurement		
P0-33	<b>Drive Output Voltage</b>	VAC	
	Displays the instantaneous output voltage from the drive to the motor		
P0-34	<b>Motor Poles Calculated</b>		
	Displays the calculated number of pole pairs when the motor pole parameter (P4-05) is set to 0 (Automatic calculation of motor poles).		
P0-35	<b>Travel Profile State</b>		
	Displays the current position on the travel curve.		
	<b>State No</b>		
	5	Motor Contactor Closing Time Active (P3-01)	
	6	Motor Connected Check Active (P10-08)	
	10	Motor Brake Release Time Active (P5-01)	
	13	DC Injection Time at start Active (P9-11)	
	14	Smooth Start Time Active (P9-08)	
	19	Accelerating to High Speed	
	18	Running at High Speed 1 (P8-06)	
	30	Running at High Speed 2 (P8-09)	
	33	Running at High Speed 3 (P8-10)	
	36	Running at High Speed 4 (P8-11)	
	39	Running at High Speed 5 (P8-12)	
	23	Decelerating to Levelling Speed	
	21	Running at Levelling Speed (P8-05)	
	46	Zero Speed holding time on disable active (P9-22)	
	47	Motor Brake Apply Delay Active (P5-02)	
	48	DC Injection Time At stop Active (P9-13)	
	49	Torque Reduction time during stopping (P4-17)	
	50	Motor Contactor Opening Time Active	
	P0-36	<b>Travel Profile Trip point</b>	
		This parameter indicates at what point on the travel curve the drive tripped.	
<b>State No</b>			
5		Motor Contactor Closing Time Active (P3-01)	
6		Motor Connected Check Active (P10-08)	
10		Motor Brake Release Time Active (P5-01)	
13		DC Injection Time at start Active (P9-11)	
14		Smooth Start Time Active (P9-08)	
19		Accelerating to High Speed	
18		Running at High Speed 1 (P8-06)	
30		Running at High Speed 2 (P8-09)	
33		Running at High Speed 3 (P8-10)	
36		Running at High Speed 4 (P8-11)	
39		Running at High Speed 5 (P8-12)	
23		Decelerating to Levelling Speed	
21		Running at Levelling Speed (P8-05)	
46		Zero Speed holding time on disable active (P9-22)	
47		Motor Brake Apply Delay Active (P5-02)	
48		DC Injection Time At stop Active (P9-13)	
49		Torque Reduction time during stopping (P4-17)	
50		Motor Contactor Opening Time Active	

Parameter Number	Parameter Description	Units
P0-37	<b>Currently active Trip code</b>	-
	This parameter indicates the current trip code.	
P0-38	<b>Trip History Log</b>	-
	Displays the last four fault codes.	
	P0-38	Last Trip 1 (Newest Trip)
	P0-38-1	Last Trip 2
	P0-38-2	Last Trip 3
P0-38-3	Last Trip 4 (Oldest Trip)	
P0-39	<b>Reserved</b>	
P0-40	<b>DC Bus Voltage</b>	V
	Displays the instantaneous DC Bus Voltage internally within the drive	
P0-41	<b>DC Bus Voltage Ripple</b>	V
	Displays the level of ripple present on the DC Bus Voltage.	
P0-42	<b>L1 Input Voltage</b>	VAC
P0-43	<b>L2 Input Voltage</b>	VAC
P0-44	<b>L3 Input Voltage</b>	VAC
P0-45	<b>Motor Thermistor Resistance</b>	$\Omega$
	Analogue Input 1 thermistor	
P0-46	<b>Motor Thermistor 2 Resistance</b>	$\Omega$
	Analogue input 2 thermistor	
P0-47	<b>Brake Resistor Active</b> 0 = Brake Resistor Off 1 = Brake Resistor On	-
P0-48	<b>IGBT Temperature</b>	$^{\circ}\text{C}$
	Displays the Instantaneous Heatsink (IGBT thermistor) Temperature measured by the drive	
P0-49	<b>Drive Internal Temperature</b>	$^{\circ}\text{C}$
	Displays the Instantaneous Internal (Control PCB) Temperature measured by the drive	
P0-50	<b>Drive Run Time Since Last Trip</b>	H:S
	Displays the running time of the drive since the last trip occurred. The first value shown is the number of hours. Pressing the Up key will display the seconds.	
	P0-50	Hours Running Since Last Trip
	P0-50-1	Seconds Running Since Last Trip
P0-51	<b>Drive Run Time Since Last Trip 2</b>	H:S
	Displays the running time of the drive since the 2 <sup>nd</sup> to last trip occurred. The first value shown is the number of hours. Pressing the Up key will display the seconds.	
	P0-51	Hours Running Since 2 <sup>nd</sup> to Last Trip
	P0-51-1	Seconds Running Since 2 <sup>nd</sup> to Last Trip
P0-52	<b>Drive Run Time Since Last Enable</b>	H:S
	Displays the total running time of the drive since the last Run command was received. The first value shown is the number of hours. Pressing the Up key will display the seconds.	
	P0-52	Run time Hours Running Since 2 <sup>nd</sup> to Last Trip
	P0-52-1	Seconds Running Since 2 <sup>nd</sup> to Last Trip

Parameter Number	Parameter Description	Units			
P0-53	<b>Drive Lifetime Operating Time</b>	H:S			
	Displays the total operating time of the drive. The first value shown is the number of hours. Pressing the Up key will display the seconds.				
	<table border="1"> <tr> <td>P0-53</td> <td>Drive Operating time (Hours)</td> </tr> <tr> <td>P0-53-1</td> <td>Drive Operating time (S)</td> </tr> </table>	P0-53	Drive Operating time (Hours)	P0-53-1	Drive Operating time (S)
P0-53	Drive Operating time (Hours)				
P0-53-1	Drive Operating time (S)				
P0-54	<b>Drive Total Run Time</b>	H:S			
	Displays the total run time of the drive. The first value shown is the number of hours. Pressing the Up key will display the seconds.				
	<table border="1"> <tr> <td>P0-54</td> <td>Drive Total Run Time (Hours)</td> </tr> <tr> <td>P0-54-1</td> <td>Drive Total Run Time (S)</td> </tr> </table>	P0-54	Drive Total Run Time (Hours)	P0-54-1	Drive Total Run Time (S)
P0-54	Drive Total Run Time (Hours)				
P0-54-1	Drive Total Run Time (S)				
P0-55	<b>Drive Heatsink Cooling Fan Total Operating Time</b>	H:S			
	Displays the total operating time of the drive internal cooling fans. The first value shown is the number of hours. Pressing the Up key will display the minutes and seconds. This is used for scheduled maintenance information				
	<table border="1"> <tr> <td>P0-55</td> <td>Drive Heatsink Cooling Fan Total Run Time (Hours)</td> </tr> <tr> <td>P0-55-1</td> <td>Drive Heatsink Cooling Fan Total Run Time (S)</td> </tr> </table>	P0-55	Drive Heatsink Cooling Fan Total Run Time (Hours)	P0-55-1	Drive Heatsink Cooling Fan Total Run Time (S)
P0-55	Drive Heatsink Cooling Fan Total Run Time (Hours)				
P0-55-1	Drive Heatsink Cooling Fan Total Run Time (S)				


Parameter Number	Parameter Description	Units
P0-56	<b>Analog Input 1 Applied Signal Value</b>	V or mA depending on signal format set in P1-03
	Displays the actual signal level applied to analog input 1 (DI4) before scaling and offsets have been applied.	
P0-57	<b>Analog Input 1 Final Signal Value</b>	V or mA depending on signal format set in P1-03
	Displays the signal level after Offset (P1-04) and Scaling (P1-05) is applied	
P0-58	<b>Analog Input 2 Applied Signal Value</b>	V or mA depending on signal format set in P1-09
	Displays the actual signal level applied to analog input 2 (DI5) before scaling and offsets have been applied.	
P0-59	<b>Analog Input 2 Final Signal Value</b>	V or mA depending on signal format set in P1-09
	Displays the signal level after Offset (P1-10) and Scaling (P1-11) is applied	
P0-60	<b>DC Bus Voltage Log</b>	V
P0-61	<b>DC Bus Voltage Ripple Log</b>	V
P0-62	<b>Heatsink Temperature Log</b>	°C
P0-63	<b>Drive Internal Temperature Log</b>	°C
P0-64	<b>Motor Current Log</b>	A
P0-65	<b>Motor Speed Log</b>	Hz/RPM/Linear
	The above parameters are used to store the history of various measured levels within the drive at various regular time intervals prior to a trip. The values are frozen when a fault occurs and can be used for diagnostic purposes	
P0-66	<b>Encoder Speed Log</b>	Hz/RPM/Linear
	The above parameters are used to store the history of various measured levels within the drive at various regular time intervals prior to a trip. The values are frozen when a fault occurs and can be used for diagnostic purposes	
P0-70	<b>Drive Type</b>	-
	Displays the type details of the drive	
	P0-70	Drive Rated Voltage
	P0-70-1	Drive Frame Size
	P0-70-2	Drive Rated Power (kW)
	P0-70-3	Number of input Phases
P0-70-4	Drive Type Code	
P0-71	<b>Option Module Type</b>	-
	Displays the type details of the drive	
	P0-71	Option Module Type
	P0-71-1	Option module firmware version major.minor
P0-71-2	Option module firmware version revision	
P0-72	<b>Drive IO Firmware Version</b>	-
	P0-72	IO Firmware version
P0-72-1	IO Firmware checksum	
P0-73	<b>Drive Power Stage Firmware Version</b>	-
	P0-73	Power Stage Firmware version
P0-73-1	Power Stage Firmware checksum	
P0-74	<b>Drive Serial Number</b>	-
	Displays the unique serial number of the drive.	
	P0-74	Serial Number (High)
	P0-74-1	Serial Number ( <b>Low</b> )
P0-75	<b>PS Read Value</b>	-
	Internal Use Only	

## 16. Rescue Operation


Rescue operation is normally used in the event of a mains borne power failure, with the primary goal of moving the elevator car at a limited motor speed for passenger evacuation, the power source comes from either DC (Batteries) or a UPS power supply as defined by the setting of P7-01 and with wiring in accordance with the connection diagrams shown below.

P7-01	Rescue Supply Type
UPS230	230VAC 1ph UPS (Default)
UPS400	400VAC 2ph UPS
bAtt	Battery Operation

### 16.1. UPS power supply connections



### 16.2. Activating UPS Rescue mode



## 17. Serial communications

### 17.1. USB-C



The drive has a USB-C connection which provides the following facilities:

- A means to power the drive display up without the need for mains power, this allows the user to navigate and edit the drive parameters using the drives built-in keypad.
- A PC connection over USB-C which can be used in conjunction with the Optitools Pro software suite. (Available as a free download from [www.invertekdrives.com/variable-frequency-drives/optidrive-elevator-core](http://www.invertekdrives.com/variable-frequency-drives/optidrive-elevator-core))

Invertek Drives recommends that an isolated cable is used between the drive and the PC.

Note: When the drive is powered from the USB-C connection only :

- Other serial communication interfaces will not operate.
- Parameter editing via keypad or USB.


### 17.2. RS-485 communications

The drive has an on-board RJ45 connector, this connector provides the following connections:

- Connection of the drive to a PC with OptiTools-Pro software installed.
- Modbus-RTU network Connection.
- CANopen network Connection.

PC Connection and network connection can be used simultaneously.

The electrical signal arrangement of the RJ45 connector is shown below :



### 17.3. PC Tool



Download PC tool here

## 18. Other Commonly Used Functions

<b>P3-04</b>	<b>Brake Resistor Resistance</b>
<b>P3-05</b>	<b>Brake Resistor Power</b>
<b>Function</b>	For software protection of the connected brake resistor, enter the rated power and resistance of the resistor into the above parameters. The drive will then monitor the brake resistor to ensure that it does not operate outside of its designed limits.
<b>Adjustment</b>	Populate the values of the brake resistor into P3-04 and P3-05 Where an external thermal protection device is fitted, and software protection is not required. Setting the parameter to zero will disable the software protection feature.

<b>P10-08</b>	<b>Motor Connected Check</b>
<b>Function</b>	This function ensures that all 3 phases of the motor are connected prior to releasing the electro-mechanical brake, helps detect breaks in the connection between the drive and the motor, for example a broken cable or a faulty contactor.  The drive will trip "OUT-Phx" if the drive detects the motor is not connected, where x is the phase that is missing e.g. "OUT-PhU"
<b>Adjustment</b>	Setting 0 means function is disabled. The correct value is one in which the audible noise level is acceptable, but the drive still detects a missing motor phase should it not be connected.

<b>P11-09</b>	<b>Output Phase Sequence</b>
<b>Function</b>	0 = U, V, W 1 = U, W, V. Direction of motor rotation when operating in a forward direction will be reversed.

<b>P6-02</b>	<b>Encoder Feedback Direction</b>
<b>Function</b>	Changes the direction of the incremental signals of the encoder feedback signal. <b>0 = A leads B when an Up command is given (Clockwise Direction)</b> <b>1 = B leads A when an Up command is given (Anti-Clockwise Direction)</b>

<b>P11-05</b>	<b>Effective Switching Frequency</b>
<b>Function</b>	IGBT Switching Frequency. Higher switching frequencies reduce the audible 'ringing' noise from the motor, and improve the output current waveform, at the expense of increased drive losses.

## 19.Safe Torque Off

### 19.1. Safe Torque Off

Safe Torque OFF will be referred to as “STO” through the remainder of this section.

#### 19.1.1. Responsibilities

The overall system designer is responsible for defining the requirements of the overall “Safety Control System” within which the drive will be incorporated; furthermore, the system designer is responsible for ensuring that the complete system is risk assessed and that the “Safety control System” requirements have been entirely met and that the function is fully verified, this must include confirmation testing of the “STO” function before drive commissioning.

The system designer shall determine the possible risks and hazards within the system by carrying out a thorough risk and hazard analysis, the outcome of the analysis should provide an estimate of the possible hazards, furthermore, determine the risk levels and identify any needs for risk reduction. The “STO” function should be evaluated to ensure it can sufficiently meet the risk level required.

#### 19.1.2. What STO Provides

The purpose of the “STO” function is to provide a method of preventing the drive from creating torque in the motor in the absence of the “STO” input signals (STO1 & STO2), this allows the drive to be incorporated into a complete safety control system where “STO” requirements need to be fulfilled.<sup>1</sup>

The “STO” function can typically eliminate the need for electro-mechanical contactors with cross-checking auxiliary contacts as per normally required to provide safety functions.<sup>2</sup>

The drive has the “STO” Function built-in as standard and complies with the definition of “Safe torque off” as defined by IEC 61800-5-2:2007.

The “STO” Function also corresponds to an uncontrolled stop in accordance with category 0 (Emergency Off), of IEC 60204-1. This means that the motor will coast to a stop when the “STO” function is activated, this method of stopping should be confirmed as being acceptable to the system the motor is driving.

The “STO” function is recognised as a fail-safe method even in the case where the “STO” signal is absent and a single fault within the drive has occurred, the drive has been proven in respect of this by meeting the following safety standards :

Safe Torque Off (STO)	IEC 61800-5-2:2016	SIL 3
	EN ISO 13849-1:2015	PL “e”
	EN 61508 (Part 1 to 7): 2010	SIL 3
	EN 60204-1: 2006 & A1: 2009	Cat 0
	EN 62061: 2005 & A2: 2015	SIL CL 3
	Independent Approval	Pending

Note : The values achieved above maybe jeopardised if the drive is installed outside of the Environmental limits detailed in section 4.2 and 7.2.

#### 19.1.3. What STO does not provide



Disconnect and ISOLATE the drive before attempting any work on it. The “STO” function does not prevent high voltages from being present at the drive power terminals.



<sup>1</sup> Note: The “STO” function does not prevent the drive from an unexpected re-start. As soon as the “STO” inputs receive the relevant signal it is possible (subject to parameter settings) to restart automatically, Based on this, the function should not be used for carrying out short-term non-electrical machinery operations (such as cleaning or maintenance work).



<sup>2</sup> Note: In some applications additional measures may be required to fulfil the systems safety function needs: the “STO” function does not provide motor braking. In the case where motor braking is required a time delay safety relay and/or a mechanical brake arrangement or similar method should be adopted, consideration should be made over the required safety function when braking as the drive braking circuit alone cannot be relied upon as a fail-safe method.



When using Gearless (Permanent Magnet) motors and in the unlikely event of a multiple output power devices failing then the motor could effectively rotate the motor shaft by 180/p degrees (Where p denotes number of motor pole pairs).

#### 19.1.4. "STO" Operation

When the "STO" inputs are energised, the "STO" function is in a standby state, if the drive is then given a "Start signal/command" (as per the start source method selected in P1-02) then the drive will start and operate normally.

When the "STO" inputs are de-energised then the STO Function is activated and stops the drive (Motor will coast), the drive is now in "Safe Torque Off" mode.

To get the drive out of "Safe Torque Off" mode then any "Fault messages" need to be reset and the drive "STO" input needs to be re-energised.

The STO inputs are positive logic inputs only and are therefore not affected by the setting of parameter P1-43 (Positive/negative logic select).

#### 19.1.5. "STO" Status and Monitoring

There are several methods for monitoring the status of the "STO" input, these are detailed below:

##### Drive Display

In Normal drive operation (Mains AC power, UPS Power or Battery Power), when the drives "STO" input is de-energised ("STO" Function activated) the drive will highlight this by displaying "InHibit".

Note: If the drive is in a tripped condition then the relevant trip will be displayed and not "InHibit").

##### Drive Status parameter

Parameter P0-03 can be viewed to see the STO input status as illustrated below :

Display value				0	0
Input Terminal				STO1	STO2

1 = Input Active

0 = Input InActive

##### Drive Output Relay and Digital Outputs

Relay 1 or the digital outputs can be used to monitor the status of the STO inputs by setting the function to 8.

For Relay 1 set P1-30 to 8.

For Digital Output 1 (DA1) set P1-15 to 8 and P1-14 to 0

For Digital Output 2 (DA2) set P1-22 to 8 and P1-21 to 0

For Digital Output 3 (DO3) set P1-28 to 8.

##### "STO" Fault Codes

Fault Code	Code Number	Description	Corrective Action
Sto-F	29	A fault has been detected within either of the internal channels of the "STO" circuit.	Refer to your Invertek Sales Partner
Sto-L	101	STO1/STO2 signals removed whilst drive running	-

#### 19.1.6. "STO" Function response time

The total response time is the time from a safety related event occurring to the components (sum of) within the system responding and becoming safe. (Stop Category 0 in accordance with IEC 60204-1)

- The response time from the "STO" inputs being de-energised to the output of the drive being in a state that will not produce torque in the motor ("STO" active) is less than 20ms.
- The response time from the "STO" inputs being de-energised to the "STO" monitoring status changing state is less than 20ms
- The response time from the drive sensing a fault in the STO circuit to the drive displaying the fault on the display/Digital output showing drive not healthy is less than 20ms.

**19.1.7. “STO” Electrical Installation**




The “STO” wiring shall be protected from inadvertent short circuits or tampering which could lead to failure of the “STO” input signal, further guidance is given in the diagrams below.

In addition to the wiring guidelines for the “STO” circuit below, section 8.2 “EMC compliant installation” should also be followed.

The drive should be wired as illustrated below; the 24Vdc signal source applied to the “STO 1 and STO 2” inputs can be either from the 24Vdc on the drive or from an External 24Vdc power supply (as per the diagram below).

**19.1.8. Recommended “STO” wiring**



**Note:** The Maximum cable length from Voltage source to the drive terminals should not exceed 25 metres.

**19.1.9. External Power supply Specification.**

<b>Voltage Rating (Nominal)</b>	24Vdc
<b>STO Logic High</b>	18-30Vdc (Safe torque off in standby)
<b>Current Consumption (Maximum)</b>	100mA

**19.1.10. Safety Relay Specification.**

The safety relay should be chosen so that at minimum it meets the safety standards in which the drive meets.

<b>Standard Requirements</b>	SIL3 or PLe or better (With Forcibly guided Contacts)
<b>Number of Output Contacts</b>	2 independent
<b>Switching Voltage Rating</b>	30Vdc
<b>Switching Current</b>	100mA

### **19.1.11. Enabling the “STO” Function**

The “STO” function is always enabled in the drive regardless of operating mode or parameter changes made by the user.

### **19.1.12. Testing the “STO” Function**

Before commissioning the system the “STO” function should always be tested for correct operation, this should include the following tests:

- With the motor at standstill, and a stop command given to the drive (*as per the primary command source selected in P1-01*):
  - De-energise the “STO” inputs (Drive will display “InHibit”).
  - Give a start command (*as per the primary command source selected in P1-01*) and check that the drive still displays “Inhibit” and that the operation is in line with section 19.1.5 Status and Monitoring
- With the motor running normally (from the drive):
  - De-energise the “STO” inputs
  - Check that the drive displays “InHibit” and that the motor stops *and* that the operation is in line with the section 19.1.4 “STO” Operation *and* section 19.1.5 “STO” Status and Monitoring.

### **19.1.13. “STO” Function Maintenance.**

Periodic testing of the entire safety circuit within which the drive STO is integrated, is a mandatory requirement. The testing should be repeated every three months or less to ensure the integrity level of the safety circuit is maintained, furthermore the function should be integrity tested following any safety system modifications or maintenance work.

If drive fault messages are observed refer to section 20 Troubleshooting for further guidance.

## 20. Troubleshooting

### 20.1. Warning Messages

Warning message	Description	Corrective Action/Further information
<b>OLd</b>	Motor Overload	Increase acceleration rate (P8-03). Reduce the load, check the load mechanically to ensure it is free, and that no jams, blockages or other mechanical faults exist. If operating a Gearless motor check the encoder offset is correct and try repeating the measurement to confirm consistent values are being measured (P4-08=3)
<b>OL-br</b>	Brake Resistor Overtemperature warning	
<b>OL-Tm</b>	Motor Overtemperature warning	
<b>OL-dr</b>	Drive Overtemperature warning	
<b>noAc in</b>	Mains Loss	Check AC Supply is connected Check AC is connected to the drive input terminals and not the drive output terminals U,V,W
<b>SEr</b>	Service Required	The time programmed in parameter P11-17 (Service time interval) has elapsed
<b>tr-Lt</b>	Travel Limit Reached	Travel direction Change counter (Rope wear Counter) as per set in parameter P10-05 has been reached

### 20.2. Fault messages and Display messages

Display message	No.	Description	Corrective Action/Further information
<b>Ai-LoS</b>	59	Analog input signal loss	
<b>AeF-01</b>	40	Autotune Failed	Measured motor stator resistance varies between phases. Ensure the motor is correctly connected and free from faults. Check the windings for correct resistance and balance.
<b>AeF-02</b>	41		Measured motor stator resistance is too large. Ensure the motor is correctly connected (motor contactor is closed) and free from faults. Check that the power rating corresponds to the power rating of the connected drive.
<b>AeF-03</b>	42		Measured motor inductance is too low. Ensure the motor is correctly connected and free from faults.
<b>AeF-04</b>	43		Measured motor inductance is too large. Ensure motor is correctly connected and free from faults. Check that the power rating corresponds to the power rating of the connected drive.
<b>AeF-05</b>	44		Measured motor parameters are not convergent. Ensure the motor is correctly connected and free from faults. Check that the power rating corresponds to the power rating of the connected drive.
<b>AeF-06</b>	45	Encoder offset measurement failed	Drive has failed to measure the Encoder offset value using autotune method 2 in P4-08. Normally Occurs on Permanent Magnet motors with Surface Mounted magnets.
<b>AeF-nA</b>	109	Selected Autotune method incorrect for the selected Motor	Use Autotune 1 (P4-08=1).
<b>bF-Err</b>	46	Brake Release Monitoring-Warning	Check Brake micro-switches, and brake release monitoring time set in P5-05 is suitable.
<b>bF-LoC</b>	47	Brake Release Monitoring-Lockout	
<b>bUS-08</b>	67	Internal Communication Error	Power Cycle Drive, remove all power sources including USB-C. If error still shows after power cycle, then Contact your local Invertek representative.
<b>bUS--</b>		Internal Communication Error	Contact your local Invertek representative.
<b>CC</b>	-	Motor Contactor Closing/opening delay time	Shown during the period set in parameter(P3-01) motor contactor Closing/Opening time allowance
<b>CF-Err</b>	96	Motor Contactor feedback Error	Motor contactor is in wrong state as indicated by feedback signal from contactor.
<b>CF9-Ch</b>	77	Drive configuration data changed.	
<b>CF9-dF</b>	78	Drive configuration mismatch PS/IO	
<b>CF9-Er</b>	79	Drive configuration data missing or corrupt.	
<b>CrFLt</b>	30.3	Critical Module Error	
<b>dAR-3</b>	98	Internal data error	
<b>dAR-E</b>	19	Internal memory fault.	1. Reset drive (Red Button) 2. Power Cycle 3. Internal Comms Link Lost Refer to your Invertek Sales Partner. Parameters not saved, defaults reloaded. Try again. If problem recurs, refer to your Invertek Sales Partner
<b>dAR-F</b>	17	Internal memory fault.	Parameters not saved, defaults reloaded. Try again. If problem recurs, refer to your Invertek Sales Partner.
<b>Ed-dARt</b>	30.7	Encoder Feedback Error	Data Loss - Fault with CLK or DATA lines
<b>Ed-Pd</b>	30.71		Propagation Delay Error (Cable too long)
<b>Ed-LoS</b>	30.72		Comms Error (excessive signal drop out) or Line Loss whilst drive is running.
<b>Ed-inc</b>	30.73		Encoder Incompatible
<b>Ed-ROS</b>	30.74		Endat ABS Overspeed
<b>Ed-SOS</b>	30.75		Endat SC Overspeed

Display message	No.	Description	Corrective Action/Further information
<i>Ed-SAb</i>	30.76		Sin Cos Line Loss
<i>Ed-1</i>	30.77		Endat Error - Light Unit Failure
<i>Ed-2</i>	30.78		Endat Error - Signal Amplitude to low
<i>Ed-3</i>	30.79		Endat Error - Position calculation error
<i>Ed-4</i>	30.8		Endat Error - Supply Overvoltage
<i>Ed-5</i>	30.81		Endat Error - Supply Undervoltage
<i>Ed-6</i>	30.82		Endat Error - Supply Overcurrent
<i>Ed-7</i>	30.83		Endat Error - Battery need replacing
<i>Ed-8</i>	30.84		Encoder Reported Unknown Error
<i>Enc-CL</i>	Tbc	Encoder Module not fitted	Encoder I/O Comms Loss - Confirm module is fitted and pushed fully home.
<i>Enc-PP</i>	99		Encoder Pulse per revolution parameter (P6-03) set as 0 with Encoder Enabled (P6-04>0)
<i>E-tr iP</i>	11	External trip	E-trip requested on control input terminals. Some settings of P1-02 require a normally closed contact to provide an external means of tripping the drive if an external device develops a fault. If a motor thermistor is connected check if the motor is too hot.
<i>Enc-Er</i>	30	Encoder Feedback Faults (Only visible when an encoder module is fitted and enabled)	Will also show sub-trip code to Encoder communication /data loss
<i>EncCFB</i>		Encoder Configuration Error	Encoder type has not been set in parameter P6-04.
<i>EncCF9</i>	100	Encoder Configuration Error	Encoder offset measurement has been attempted with Encoder disabled, check Encoder is Enabled (P6-05=1)
<i>E-103</i>	103	Unexpected PS Firmware Change	
<i>E-250</i>	250	Internal Error	
<i>E-251</i>	251	Module not supported	
<i>E-252</i>	252	IO not supported	
<i>E-253</i>	253	Hardware ID not supported	
<i>E-254</i>	254	Drive ID not supported	
<i>E-255</i>	255		
<i>F<sub>LT</sub>-dc</i>	13	Excessive DC Ripple	The DC Bus Ripple Voltage level is displayed in parameter P0-41 Check all three supply phases are present and within the 3% supply voltage level imbalance tolerance. Reduce the motor load.
<i>F-Ptc</i>	21	Motor PTC Over Temperature	The connected motor PTC device has caused the drive to trip
<i>F-tY</i>		Motor KTY84 Thermistor Fault	
<i>FAn-F</i>	22	Cooling Fan Fault	Check and if necessary, replace the drive internal cooling fan
<i>HtLO</i>	30.29		Quadrature TTL Over-speed
<i>h 0-1</i>	15	Instantaneous over current on drive output.	Refer to fault 3 below
<i>I<sub>LT</sub>-trP</i>	04	Drive has tripped on overload after delivering >100% of value in P4-03 for a period of time.	Increase acceleration rate (P8-03) or reduce the load. Check motor cable length does not exceed exceeds 100m (screened cable), or 150m (un-screened cable). Ensure the motor nameplate parameters are correctly entered in P4-02, P4-03, P4-04, P4-05. If operating in Vector mode (P4-01 – 0 or 1), also check the motor power factor in P4-07 and ensure an autotune has been successfully completed for the connected motor. Check the load mechanically to ensure it is free, and that no jams, blockages or other mechanical faults exist. If operating a Gearless motor check the encoder offset is correct and try repeating the measurement to confirm consistent values are being measured (P4-08=3)
<i>InLoSS</i>	102	3 Phase input loss whilst running	
<i>IC-A</i>	30.2		Encoder Channel A Fault
<i>IC-b</i>	30.23		Encoder Channel B Fault
<i>IC-2</i>	30.26		Encoder Channel Z Fault
<i>L1-LoS</i>	92	L1 Phase is not present	
<i>L2-LoS</i>	93	L2 Phase is not present	
<i>L3-LoS</i>	94	L3 Phase is not present	
<i>no-FLt</i>	0	No Fault	
<i>odr-Er</i>	55	Wrong Run Sequence	Confirm STO and direction input is applied <b>before</b> speed commands. This function can be disabled by setting P11-23 to 1:Disabled
<i>0-HEAt</i>	23	Ambient Temperature too High	The measured temperature around the drive is above the operating limit of the drive. Ensure the drive internal cooling fan is operating Ensure that the required space around the drive as shown in section 7.2, and that the cooling airflow path to and from the drive is not restricted Increase the cooling airflow to the drive Reduce the effective switching frequency setting in parameter P11-05 Reduce the load on the motor / drive

Display message	No.	Description	Corrective Action/Further information
<b>OUt-F</b>	26	Drive output fault	Drive output fault, Confirm all 3 motor phases are connected, check that output contactors are closing fully, not arcing, or not opening whilst the drive is running. Confirm contactor control connections to the drive are correct.
<b>O-t</b>	08	Heatsink over temperature	The heatsink temperature can be displayed in P0-48. Check the drive ambient temperature Ensure the drive internal cooling fan is operating Ensure there is the required space around the drive as shown in section 7.2, and that the cooling airflow path to and from the drive is not restricted Reduce the effective switching frequency setting in parameter P11-05 Reduce the load on the motor / drive
<b>O1-b</b>	01	Brake channel over current	Ensure the connected brake resistor is above the minimum permissible level for the drive – refer to the ratings shown in section 6. Check the brake resistor and wiring for possible short circuits.
<b>OL-br</b>	02	Brake resistor overload	The drive software has determined that the brake resistor is overloaded (based on the values entered in P3-04 and P3-05), and trips to protect the resistor. Always ensure the brake resistor is being operated within its designed parameter before making any parameter or system changes. To reduce the load on the resistor, increase deceleration time P8-04, reduce the load inertia or add further brake resistors in parallel, observing the minimum resistance value for the given drive.
<b>O-I</b>	03	Instantaneous over current on drive output (Triggered from Drive Output Current Measurement)	<b>Fault Occurs on Drive Enable</b> Check the motor and motor connection cable for phase – phase and phase – earth short circuits. Check the load mechanically for a jam, blockage, or stalled condition. Is the drive sized correctly for the connected motor? Ensure the motor nameplate parameters are correctly entered in P4-02, P4-03, P4-04, P4-05. If operating in Vector mode (P4-01 – 0 or 1), also check the motor power factor in P4-07 and ensure an autotune has been successfully completed for the connected motor. If operating in Enhanced V/F mode reduce the Boost voltage setting in P4-09 Increase the acceleration ramp up time in P8-03 If the connected motor has a holding brake, ensure the brake is correctly connected and controlled, and is releasing correctly. If operating a Gearless motor check the encoder offset is correct and try repeating the measurement to confirm consistent values are being measured (P4-08=3).  <b>Fault Occurs When Running</b> If operating in Vector mode (P4-01 – 0 or 1, 3), reduce the speed loop gains as described in section 13.3
<b>OUt-PH</b>	49	Output phase loss	Check all 3 motor phases are connected, confirm that motor contactor is closing
<b>OUt-U</b>	88	U Phase PWM output Loss	
<b>OUt-V</b>	89	V Phase PWM output Loss	
<b>OUt-W</b>	90	W Phase PWM output Loss	
<b>O-volt</b>	06	Over voltage on DC bus	Check that the lift has been correctly balanced. Check that a brake resistor is connected correctly to terminals +DC and BR. Check the resistance of the brake resistor complies with the values in section 6. If the fault occurs on stopping or during deceleration, increase the deceleration time in P8-04 If operating in Vector Mode (P4-01 = 0,1,3), reduce the speed loop gains as detailed in section 13.3 Check that the mains voltage level is within the range detailed in section 6. The value of the DC Bus Voltage can be displayed in P0-40
<b>OL-br</b>	58	Brake resistor overtemperature	Based on Brake resistor over temperature feedback via drive terminals.
<b>O1-U</b>	81	Output (Motor) U Phase overcurrent	
<b>O1-V</b>	82	Output (Motor) V Phase Loss overcurrent	
<b>O1-W</b>	83	Output (Motor) W Phase Loss overcurrent	
<b>O1-2</b>	84	Ground current fault	
<b>OPH-U</b>	85	Output (Motor) U Phase Loss	U phase is not connected to the drive, check that output contactors are closing fully, not arcing, or not opening whilst the drive is running, and see P10-08 (Motor connected check).

Display message	No.	Description	Corrective Action/Further information
<b>OPh-U</b>	86	Output (Motor) V Phase Loss	V phase is not connected to the drive, check that output contactors are closing fully, not arcing, or not opening whilst the drive is running, and see P10-08 (Motor connected check)
<b>OPh-W</b>	87	Output (Motor) W Phase Loss	W phase is not connected to the drive, check that output contactors are closing fully, not arcing, or not opening whilst the drive is running, and see P10-08 (Motor connected check)
<b>O-SPd</b>	91		Shown when the rotor speed is higher than 150% of maximum speed (P8-01) (immediate trip) or higher than 125% maximum speed (P8-01) for more than 100ms, whichever happens first
<b>P-ASy</b>	95	Input phase voltage imbalance	
<b>P-dEF</b>	10	Factory Default parameters have been loaded	Press STOP key, the drive is now ready to be configured for the required application
<b>P-LOSS</b>	14	Input phase loss trip	Drive intended for use with a 3 phase supply, one input phase has been disconnected or lost.
<b>Pr09-2</b>			1. Reset drive (Red Button) 2. Power Cycle 3. Internal Comms Link Lost Refer to your Invertek Sales Partner.
<b>PE</b>	30.2		Parameterisation Error
<b>P5-trP</b>	05	Instantaneous over current on drive output (Triggered from Power Module Current Measurement)	Refer to fault 3 above
<b>SC-Ab</b>	30.5		Sin Cos A B Line Loss
<b>SC-C</b>	30.51		Sin Cos C Line Loss
<b>SC-d</b>	30.52		Sin Cos D Line Loss
<b>Sc-F01</b>	50	Modbus comms fault	A valid Modbus telegram has not been received within the watchdog time limit set in P5-06 Check the network master / PLC is still operating, Check the connection cables. Increase the value of P2-06 to a suitable level
<b>Sc-F02</b>	51	CAN Open comms trip	A valid CAN open telegram has not been received within the watchdog time limit set in P5-06 Check the network master / PLC is still operating, Check the connection cables. Increase the value of P2-06 to a suitable level
<b>Sc-F03</b>	52	Communications Option Module Fault	Internal communication to the inserted Communication Option Module has been lost. Check the module is correctly inserted
<b>Sc-F04</b>	53	IO card comms trip	Internal communication to the inserted Option Module has been lost. Check the module is correctly inserted
<b>SC-OS</b>	30.53		Sin Cos Over-speed
<b>SC-LoS</b>	97		1. Reset drive (Red Button) 2. Power Cycle 3. Internal Comms Link Lost Refer to your Invertek Sales Partner.
<b>SC-th</b>	27	Motor thermistor short circuit	Check motor thermistor for wiring faults, check thermistor has not failed.
<b>ShoS</b>	30.1	Motor Over Speed	
<b>SP-Err</b>	31	Speed Error	Encoder Speed Error. The % error between the estimated (open loop)/measured encoder feedback speed and the actual motor speed is greater than the value set in P6-11 for the time set in P6-12 <ul style="list-style-type: none"> <li>Confirm that the speed loop gains have been optimised.</li> <li>In Gearless applications can be caused by excess rollback, see section 14 Comfort Optimisation</li> <li>If operating a Gearless motor check the encoder offset is correct and try repeating the measurement to confirm consistent values are being measured (P4-08 to 3)</li> <li>In Geared Open loop applications this can be caused by the motor stalling, check : <ul style="list-style-type: none"> <li>Motor data is correct, and an auto-tune has been performed.</li> <li>Motor rated current is set correctly.</li> <li>Magnetising current in P4-28 is not too high.</li> <li>Brake is releasing.</li> </ul> </li> </ul>
<b>Sto-L</b>	101	STO inputs opened whilst drive running	
<b>Sto-F</b>	29	Internal STO circuit Error	Check supply to terminals STO1 and STO2 is >18V, otherwise Refer to your Invertek Sales Partner
<b>tLd</b>	30.3		Quadrature HTL Over-speed
<b>th-FLt</b>	16	Faulty thermistor on heatsink.	Refer to your Invertek Sales Partner.
<b>tr-Lt</b>	Tbc	Travel limit counter reached	The value set in parameter P10-05 (Travel Direction Change Counter limit) has been reached.
<b>U-dEF</b>	20	User Parameter Defaults	User Parameter defaults have been loaded. Press the Stop key.
<b>U-uolt</b>	07	Under voltage on DC bus	This occurs routinely when power is switched off. If it occurs during running, check the incoming supply voltage, and all connections into the drive, fuses, contactors etc. If in rescue mode confirm that the voltage is within the range detailed in section 6.5 If in rescue mode try decreasing rescue mode speed (P7-03)
<b>UPS-L</b>	110	UPS Overload	Whilst operating in Rescue mode the output power to the motor exceeded the value of UPS rating (P7-04) for the time set in parameter (P7-16) UPS Overload Time Limit, Reduce Rescue Mode Speed/Motor Load.
<b>U-t</b>	09	Under temperature	Trip occurs when ambient temperature is less than -20°C. The temperature must be raised over -20°C in order to start the drive.

Display message	No.	Description	Corrective Action/Further information
<i>USB C</i>	-	Drive is being powered from the USB_C port on the front of the drive.	
<i>USB P</i>	-	Drive is being powered from the USB_C port on the front of the drive and data transmitting via USB_C is disabled ( <b>P2-13</b> set to 0)	
<i>USR-PS</i>	-	Save User defaults action has been performed	Shown when <b>P11-01</b> is set to 1 to save values as user default parameters.
<i>USR-cL</i>	-	Clear User defaults action has been performed	Shown when <b>P11-01</b> is set to 2 to clear user default parameters.
<i>4-20 F</i>	18	4-20mA Signal Lost	The reference signal on Analog Input 1 or 2 (DI4/DI5) has dropped below the minimum threshold of 3mA. Check the signal source and wiring to the drive terminals.
<i>4-20 I</i>	28	Current input >25mA	Reduce current to maximum of 20mA on terminals DI4/DI5

### 20.3. Encoder Module Status LED's .

	LED	Function	Indication
	Top LED	Power Status	Red = Power on
			Off = No power
	Bottom LED	Error Status	Off = No Error
			Green = No Signal connected/received
			Green Flashing = Error

**Intentional Blank Page**

**Intentional Blank Page**

## 21. Drive and Application Details

---

<b>Building Name:</b>	
<b>Equipment No/Name:</b>	
<b>Drive Serial Number:</b>	
<b>Motor Details:</b>	
<b>Date of Installation</b>	
<b>Notes</b>	
<b>Parameter Changes</b>  <i>Tip :</i> Setting Parameter <b>P0-00</b> to 0 will show all parameters that are different from factory defaults	



82-ECMAN-IN\_V1.0

EFFECTIVE: 12-11-2024

Invertek Drives Ltd. Offa's Dyke Business Park, Welshpool, Powys SY21 8JF United Kingdom Tel: +44 (0)1938 556868 Fax: +44 (0)1938 556869