

Sensors and Transmitters Application

Intuitive, the **SigNow** software allows you to configure **NOVUS signal transmitters** easily and quickly.

The application allows you to save the configuration to file. This file can be used as a backup or can be sent to other devices.

It also has a diagnostic function to verify if the equipment is reading the process variable correctly.

On mobile devices, the **SigNow Mobile** app allows the mobile to power the device to be configured with the USB OTG adapter. This makes it easy to use in the field.




Quick access to the product manual



Automatic search for updates



Allows you to open tickets for technical support



Compatible with Windows PC and mobile devices



Easy and intuitive interface



Allows configuration backup



A single tool for the entire line of NOVUS transmitters

Technical Specifications

PC/Laptop Minimum Requirements	PC/Laptop Minimum Requirements 2 GHz dual-core processor or higher 4 GB RAM (8 GB recommended) Monitor and video card with a minimum resolution of 1280 x 720 500 MB of hard disk space Operating system: Windows 10 or higher USB Port Network interface (for software features that require Internet access)
Minimum Smartphone Requirements	Compatible with Android operating system (version 9.0 or higher)
Languages	Portuguese, Spanish, English, and French
Software Update	Software provides automatic updates (Internet access required)

Features	Parameter configuration Send batch configuration Firmware update Diagnostic Forcing Input Signals Forcing Output Signals Open Device Manual Open Technical Support ticket
Communication Interfaces	PC/Laptop: USB and Bluetooth Smartphone: USB OTG and Bluetooth
Compatible Devices	TxBlock-USB, TxBBlock-USB-RTD, TxRail-USB, TL400, TxIsoBlock-HRT, TxIsoRail-HRT, TxIsoRail, and NP640
Reports	Generates a configuration report with the values of all configured parameters

20230214 - FL_SigNow - EN